



Seltmann
Weiden

HOTEL

HIGH LIGHTS



MADE IN GERMANY

We produce in Germany



INDEX

4-5	GOOD MOOD white »Mármaros«	40-41	MERAN Fine Dining
6-7	MAXIM Basic	42-43	SALZBURG
8-9	MAXIM Organic	44-45	MARIENBAD
10-11	MAXIM Coup Fine Dining	46-51	COUP FINE DINING »Fashion«
12-13	DIAMANT	52-53	COUP FINE DINING »Karma«
14-15	COUP FINE DINING	54-57	COUP FINE DINING BUFFET GOURMET »Fantastic«
16-17	SAVOY	58-61	COUP FINE DINING »Country Life«
18-19	SAVOY square / rectangular	62-63	COUP FINE DINING »Reflections« »Growth«
20-21	SAVOY »Grand Blue«	64-65	COUP FINE DINING »Blue Sea«
22-25	MANDARIN incl. Event	66-67	MERAN »Springcolors«
26-27	COFFE-E-MOTION	68-69	VIP.COLLECTION
28-29	LAGUNA	70-71	BUFFET PLUS
30-31	LUXOR Fine cream	72-75	BUFFET GOURMET
32-35	MERAN Basic	76-77	MUG TO GO
36-37	MERAN Steak & more	78-79	COMMUNITY
38-39	MERAN Organic	80-81	VITALIS / IMPERIAL



GOOD MOOD

WHITE | »MÁRMAROS«

ITEM DESCRIPTION			PU ¹	Item-No	ITEM DESCRIPTION			PU ¹	Item-No
Coffee pot 1 0,38 ltr. / 13.3 oz.			2	001.751096 ² 001.751228 ³	Bowl semi-high M5399-12 12 cm / 4.8 inch			2	001.751424 ² 001.751437 ³
Sugar Bowl 0,18 ltr. / 6.3 oz.			1	001.751108 ² 001.751232 ³	Bowl semi-high M5399-16 16 cm / 6.3 inch			2	001.751090 ² 001.751220 ³
Creamer 0,14 ltr. / 4.7 oz.			1	001.751102 ² 001.751235 ³	Bowl semi-high M5399-21 21 cm / 8.2 inch			1	001.751091 ² 001.751221 ³
Mocha cup 0,09 ltr. / 3.3 oz.			6	001.751103 ² 001.751236 ³	Bowl semi-high M5399-26 26 cm / 10.3 inch			1	001.751092 ² 001.751222 ³
Saucer M5402-13 13 cm / 5.2 inch			6	001.751099 ² 001.751231 ³	Bowl high M5400-16 16 cm / 6.4 inch			1	001.751425 ² 001.751438 ³
Coffee cup 0,18 ltr. / 6.3 oz.			6	001.751104 ² 001.751237 ³	Bowl high M5400-21 21 cm / 8.4 inch			1	001.751426 ² 001.751439 ³
Cappuccino 0,25 ltr. / cup 8.7 oz.			6	001.751107 ² 001.751240 ³	Plate deep coup M5404-16 16 cm / 6.3 inch			4	001.751428 ² 001.751441 ³
Mug with handle 0,28 ltr. / 9.7 oz.			6	001.751106 ² 001.751239 ³	Plate deep coup M5404-21 21 cm / 8.3 inch			2	001.751427 ² 001.751440 ³
Combi saucer M5402-16 16 cm / 6.3 inch			6	001.751105 ² 001.751238 ³	Plate deep coup M5404-26 26 cm / 10.3 inch			2	001.751429 ² 001.751442 ³
Plate flat M5397-30 30 cm / 11.9 inch			2	001.751089 ² 001.751219 ³	Bowl high 8 cm / 3.1 inch			6	001.751100 ² 001.751223 ³
Plate flat M5397-28 28 cm / 11.1 inch			2	001.751088 ² 001.751218 ³	Bowl low M5403 8 cm / 3.1 inch			6	001.751101 ² 001.751224 ³
Plate flat M5397-26 26 cm / 10.2 inch			6	001.751087 ² 001.751217 ³					
Plate flat M5397-21 21 cm / 8.2 inch			6	001.751430 ² 001.751443 ³					
Plate flat M5397-16 16 cm / 6.3 inch			6	001.751086 ² 001.751216 ³					
Plate flat oval M5398-29 29 x 21 cm / 11.6 x 8.3 inch			2	001.751093 ² 001.751225 ³					
Plate flat oval M5398-32 32 x 23 cm / 12.7 x 9.0 inch			2	001.751094 ² 001.751226 ³					
Plate flat oval M5398-36 36 x 26 cm / 14.4 x 10.2 inch			2	001.751095 ² 001.751227 ³					







²white uni

³»Mármaros« 57570

¹ PU = Packing Unit



M

AXIM

BASIC



ITEM DESCRIPTION	PU ¹	Item-No ²
 Coffee pot 1 0,38 ltr. / 12.7 oz.	2	001.724967
 Tea pot 1 0,55 ltr. / 18.3 oz.	2	001.724970
 Warming plate small	1	001.724994
 Tea strainer (ACCESSOIRE)	2	001.750850
 Rest for tea strainer / Sugar bag container	6	001.726871
 Sugar bowl 2 0,28 ltr. / 9.3 oz.	1	001.724974
 Sugar dish 8 cm / 3.2 inch	12	001.724973
 Creamer 00 0,03 ltr. / 1.0 oz.	12	001.724977
 Creamer 1 0,15 ltr. / 5.0 oz.	1	001.724978
 Creamer 2 0,25 ltr. / 8.3 oz.	1	001.724979
 Mocha cup 0,09 ltr. / 3.0 oz.	6	001.724984
 Saucer 13,5 cm / 5.4 inch	6	001.724983
 Coffee cup 1 0,18 ltr. / 6.0 oz.	6	001.724985
 Saucer 1 16,5 cm / 6.7 inch	6	001.724991
 Coffee cup 2 0,16 ltr. / 5.3 oz.	6	001.724986
 Saucer 1 16,5 cm / 6.7 inch	6	001.724991
 Milkcoffee cup 0,25 ltr. / 8.3 oz.	6	001.724987
 Saucer 1 16,5 cm / 6.7 inch	6	001.724991
 Breakfast cup 0,32 ltr. / 10.7 oz.	6	001.724988
 Saucer 1 16,5 cm / 6.7 inch	6	001.724991
 Mug with handle 0,28 ltr. / 9.3 oz.	6	001.724992
 Mocha cup non stackable 0,09 ltr. / 3.0 oz.	6	001.724982
 Saucer 13,5 cm / 5.4 inch	6	001.724983
 Coffee cup non stackable 0,18 ltr. / 6.0 oz.	6	001.724989
 Saucer 1 16,5 cm / 6.7 inch	6	001.724991
 Chocolate cup non stackable 0,22 ltr. / 7.3 oz.	6	001.724990
 Saucer 1 16,5 cm / 6.7 inch	6	001.724991
 Milkcoffee cup non stackable 0,37 ltr. / 12.3 oz.	6	001.724980
Saucer 1 16,5 cm / 6.7 inch	6	001.724991
Mug with handle non stackable 0,28 ltr. / 9.3 oz.	6	001.724993
Tea cup 0,21 ltr. / 7.0 oz.	6	001.724981
Saucer 1 16,5 cm / 6.7 inch	6	001.724991
Cup 0,42 ltr. / 14.0 oz.	6	001.732567
Saucer 1 16,5 cm / 6.7 inch	6	001.724991

ITEM DESCRIPTION	PU ¹	Item-No ²
 Plate flat 33 cm / 13.1 inch	6	001.724938
 Plate flat 30 cm / 11.9 inch	6	001.724937
 Plate flat 28 cm / 11.2 inch	6	001.724936
 Plate flat 26 cm / 10.3 inch	6	001.724935
 Plate flat 23 cm / 9.1 inch	6	001.724934
 Plate flat 21,5 cm / 8.5 inch	6	001.724933
 Plate flat 17 cm / 6.7 inch	6	001.724932
 Plate deep 23 cm / 9.1 inch	6	001.724939
 Salad plate 19 cm / 7.5 inch	6	001.724949
 Pasta plate deep 30 cm / 12.0 inch	2	001.724950
 Pasta plate deep 27 cm / 10.8 inch	2	001.724951
 Soup cup 0,27 ltr. / 10.0 oz.	6	001.724940
 Saucer 1 16,5 cm / 6.7 inch	6	001.724991
 Eventbowl oval 5257 18 cm / 7.1 x 4.9 inch	2	001.724941
 Gravy boat 0,45 ltr. / 15.0 oz.	2	001.724952
 Gravy boat 0,15 ltr. / 5.0 oz.	4	001.724953
 Bowl small 8,5 cm / 3.4 inch	6	001.724946
 Bowl large 11 cm / 4.4 inch	6	001.724945
 Party-spoon	6	001.724997
 Bowl round 13 cm / 5.2 inch	4	001.724942
 Bowl round 15 cm / 5.9 inch	2	001.724943
 Bowl round 18 cm / 7.1 inch	2	001.724944
 Bowl round 21 cm / 8.3 inch	2	001.724947
 Bowl round 24 cm / 9.4 inch	2	001.724948
 Oval plate flat 25 cm / 10.0 x 7.0 inch	2	001.724962
 Oval plate flat 28 cm / 11.2 x 8.3 inch	2	001.724963
 Oval plate flat 31 cm / 12.3 x 9.4 inch	2	001.724964
 Oval plate flat 35 cm / 13.9 x 10.9 inch	2	001.724965
Egg cup with rest	6	001.724954
Set salt and pepper	1	001.724961

¹ PU = Packing Unit
² Item-No refers to undecorated articles



ITEM DESCRIPTION	PU ¹	Item-No ²
Gourmet-plate flat organic M5340 34 cm / 13.5 x 11.3 inch	2	001.725345
Gourmet-plate flat organic M5318 29,5 cm / 11.6 x 9.3 inch	6	001.725344
Gourmet-plate flat organic M5319 24 cm / 9.5 x 7.8 inch	6	001.725343
Gourmet-plate flat organic M5339 19 cm / 7.5 x 6.5 inch	6	001.725342
Gourmet-bowl deep organic M5317 26 cm / 9.8 x 8.6 inch	2	001.725350
Gourmet-bowl deep organic M5316 20 cm / 7.8 x 6.5 inch	2	001.725349
Gourmet-bowl deep organic M5374 16 cm / 6.2 x 5.4 inch	4	001.725348
Gourmet-bowl deep organic M5373 12 cm / 4.7 x 3.9 inch	6	001.725347
Gourmet-bowl deep organic M5372 8 cm / 3.3 x 2.6 inch	6	001.725346

ITEM DESCRIPTION	PU ¹	Item-No ²
Coffee cup organic 0,21 ltr. / 7.0 oz.	6	001.725355
Cappuccino cup organic 0,28 ltr. / 9.3 oz.	6	001.725356
Milkcoffee cup organic 0,37 ltr. / 12.3 oz.	6	001.725357
Tea cup organic 0,22 ltr. / 7.3 oz.	6	001.725358
Mug with handle organic 0,33 ltr. / 10.7 oz.	6	001.725363
Saucer (combi) organic M5375 19 cm / 7.5 x 6.5 inch	6	001.725362
Mocha cup organic 0,11 ltr. / 3.7 oz.	6	001.725359
Tea cup organic 0,16 ltr. / 5.3 oz.	6	001.725360
Saucer (combi) organic M5376 15 cm / 5.9 x 5.2 inch	6	001.725361
Sugar bowl with cover organic M5342 0,25 ltr. / 8.3 oz.	1	001.725351
Creamer organic M5341 0,25 ltr. / 8.3 oz.	1	001.725354



¹ PU = Packing Unit
² Item-No refers to undecorated articles

M

AXIM

COUP FINE DINING



ITEM DESCRIPTION	PU ¹	Item-No ²	ITEM DESCRIPTION	PU ¹	Item-No ²
Espresso cup M5389 0,08 ltr. / 2.7 oz.	6	001.744594	Platter coup M5379-33x18-D 33 x 18 cm / 13.0 x 7.0 inch	2	001.733825
Coffee cup M5389 0,19 ltr. / 6.3 oz.	6	001.744595	Platter coup M5379-40x25,5-D 40 x 25,5 cm / 16.0 x 10.2 inch	2	001.729622
Cappuccino cup M5389 0,22 ltr. / 7.3 oz.	6	001.744596	Platter coup M5379-43x19-D 43 x 19 cm / 17.1 x 7.5 inch	2	001.729623
Tea cup 0,28 ltr. / 9.3 oz.	6	001.745041	Platter coup M5379-35x11-D 35 x 11 cm / 13.9 x 4.5 inch	2	001.733824
Milkcoffee cup M5389 0,35 ltr. / 11.7 oz.	6	001.744597	Platter coup M5379-44x14-D 44 x 14 cm / 17.4 x 6.0 inch	2	001.729624
Mug with handle M5389 0,28 ltr. / 9.3 oz.	6	001.744598	Duo plate 44 cm / 17.5 x 5.6 inch	2	001.732566
Saucer square M5387 13 x 13 cm / 5.2 x 5.2 inch	6	001.744599	Bowl high 0,18 ltr. / 6.0 oz.	6	001.732565
Saucer square M5387 16 x 16 cm / 6.3 x 6.3 inch	6	001.744600	Bowl low 0,21 ltr. / 7.0 oz.	6	001.732564
Saucer round M5390 13,5 cm / 5.2 inch	6	001.744601	Plate flat coup square M5383 29 x 29 cm / 11.5 x 11.5 inch	4	001.743541
Saucer round M5390 16,5 cm / 6.4 inch	6	001.744602	Plate flat coup square M5383 26 x 26 cm / 10.2 x 10.2 inch	6	001.743540
Showplate flat M5380-33-D 33 cm / 13.1 inch	4	001.729621	Plate flat coup square M5383 22 x 22 cm / 8.7 x 8.7 inch	6	001.743539
Plate flat coup M5380-30-D 30 cm / 12.0 inch	4	001.729615	Plate flat coup square M5383 16,5 x 16,5 cm / 6.5 x 6.5 inch	6	001.743538
Plate flat coup M5380-28-D 28 cm / 11.0 inch	6	001.729614	Bowl coup square M5384 26 x 26 cm / 10.2 x 10.2 inch	4	001.743546
Plate flat coup M5380-26-D 26 cm / 10.3 inch	6	001.729613	Bowl coup square M5384 22 x 22 cm / 8.6 x 8.6 inch	6	001.743545
Plate flat coup M5380-21,5-D 21,5 cm / 8.5 inch	6	001.729612	Bowl coup square M5384 17,5 x 17,5 cm / 6.9 x 6.9 inch	6	001.743544
Plate flat coup M5380-16,5-D 16,5 cm / 6.5 inch	6	001.729611	Bowl coup square M5384 13 x 13 cm / 5.0 x 5.0 inch	6	001.743543
Bowl coup M5381-28-D 28 cm / 11.0 inch	4	001.729620	Plate flat coup rectangular M5385 35 x 20 cm / 13.9 x 8.0 inch	2	001.743542
Bowl coup M5381-26-D 26 cm / 10.3 inch	6	001.729619	Plate flat coup rectangular M5386 25,5 x 18 cm / 10.2 x 7.0 inch	2	001.743547
Bowl coup M5381-23-D 23 cm / 9.2 inch	6	001.729618	Plate flat coup rectangular M5388 38 x 14 cm / 15.2 x 5.6 inch	2	001.743548
Bowl coup M5381-20-D 20 cm / 7.9 inch	6	001.729617			
Bowl coup M5381-14,5-D 14,5 cm / 5.7 inch	6	001.729616			

¹ PU = Packing Unit
² Item-No refers to undecorated articles





D IAMANT


	ITEM DESCRIPTION	PU ¹	Item-No ²
	Coffee pot 1 0,38 ltr. / 12.7 oz.	2	001.700797
	Tea pot 1 0,45 ltr. / 15.0 oz.	2	001.700798
	Warming plate 1069 small	1	001.700822
	Tea strainer (ACCESSOIRE)	2	001.750850
	Rest for tea strainer	6	001.700819
	Sugar bowl 2 0,21 ltr. / 7.0 oz.	1	001.700799
	Creamer 00 0,03 ltr. / 1.0 oz.	12	001.700800
	Creamer 1 0,15 ltr. / 5.0 oz.	1	001.700801
	Creamer 2 0,25 ltr. / 8.3 oz.	1	001.700802
	Creamer 4 0,50 ltr. / 18.7 oz.	1	001.720210
	Mocha cup 0,08 ltr. / 2.7 oz.	12	001.700810
	Saucer 13,5 cm / 5.3 inch	12	001.700809
	Coffee cup 1 0,18 ltr. / 6.0 oz.	6	001.700812
	Saucer 1 17,1 cm / 6.7 inch	6	001.700811
	Coffee cup 2 0,16 ltr. / 5.3 oz.	6	001.700814
	Saucer 1 17,1 cm / 6.7 inch	6	001.700811
	Milkcoffee cup 0,25 ltr. / 8.3 oz.	6	001.700816
	Saucer 1 17,1 cm / 6.7 inch	6	001.700811
	Mug with handle 0,28 ltr. / 9.3 oz.	6	001.700820
	Mocha cup non stackable 0,09 ltr. / 2.7 oz.	12	001.700806
	Saucer 13,5 cm / 5.3 inch	12	001.700809
	Coffee cup non stackable 0,23 ltr. / 7.7 oz.	6	001.700808
	Saucer 1 17,1 cm / 6.7 inch	6	001.700811
	Milkcoffee cup non stackable 0,37 ltr. / 12.3 oz.	6	001.705625
	Saucer 1 17,1 cm / 6.7 inch	6	001.700811
	Mug with handle non stackable 0,30 ltr. / 10.0 oz.	6	001.700821
	Tea cup 0,21 ltr. / 7.0 oz.	6	001.700804
	Saucer 1 17,1 cm / 6.7 inch	6	001.700811
	Vase	2	001.700823
	Candleholder	2	001.700824
	Napkin ring	6	001.703774
	Plate flat 33 cm / 13.0 inch	6	001.700773
	Plate flat 31,5 cm / 12.4 inch	6	001.701737
	Plate flat 29 cm / 11.4 inch	6	001.700775
	Plate flat 26 cm / 10.3 inch	6	001.700772
	Plate flat 22,5 cm / 9.0 inch	6	001.700774
	Plate flat 19 cm / 7.7 inch	6	001.700771
	Plate flat 17 cm / 6.8 inch	6	001.700770

	ITEM DESCRIPTION	PU ¹	Item-No ²
	Plate deep 23 cm / 9.3 inch	6	001.700776
	Salad plate 20 cm / 8.0 inch	6	001.700784
	Pasta plate deep 30 cm / 11.7 inch	2	001.700785
	Pasta plate deep 27 cm / 10.7 inch	2	001.700786
	Soup cup 0,27 ltr. / 9.0 oz.	6	001.700778
	Saucer 1 17,1 cm / 6.7 inch	6	001.700811
	Eventbowl oval 5257 18 cm / 7.0 x 5.0 inch	2	001.700779
	Gravy boat 0,50 ltr. / 16.7 oz.	2	001.700787
	Gravy boat 0,15 ltr. / 5.0 oz.	4	001.700790
	Butter pad small* 0,06 ltr. / 2.0 oz.	2	001.703727
	Butter pad large** 0,13 ltr. / 4.3 oz.	2	001.703726
	Bowl round 15 cm / 5.7 inch	4	001.700780
	Bowl round 18 cm / 7.4 inch	2	001.705623
	Bowl round 23 cm / 9.2 inch	2	001.700781
	Bowl round 26 cm / 10.0 inch	2	001.700782
	Bowl round 29 cm / 11.0 inch	2	001.700783
	Relish oval deep 24 cm / 9.5 x 7.6 inch	2	001.700788
	Oval plate flat 33 cm / 13.0 x 10.4 inch	2	001.700795
	Oval plate flat 38 cm / 15.2 x 12.2 inch	2	001.700796
	Egg cup with rest	6	001.700791
	Set salt and pepper	1	001.700794
	Salt shaker	2	001.700792
	Pepper shaker	2	001.700793
	Eventplate deep round 26 cm / 10.6 inch	2	001.712395
	Eventplate flat round 25 cm / 10.0 inch	6	001.712394
	Eventbowl sloping 10 cm / 3.9 inch	6	001.712396
	Eventbowl sloping 18 cm / 7.2 inch	4	001.712398
	Eventbowl sloping 22 cm / 8.6 inch	2	001.712399

¹ PU = Packing Unit
² Item-No refers to undecorated articles



C OUP FINE DINING

	ITEM DESCRIPTION	PU ¹	Item-No ²		ITEM DESCRIPTION	PU ¹	Item-No ²
	Coffee pot 0,38 ltr. / 13.3 oz.	2	001.742664		Plate flat coup square M5383 29 x 29 cm / 11.5 x 11.5 inch	4	001.742656
	Tea pot 0,65 ltr. / 21.6 oz.	2	001.742675		Plate flat coup square M5383 26 x 26 cm / 10.3 x 10.3 inch	6	001.742655
	Sugar bowl (LIFE) 0,26 ltr. / 8.6 oz.	1	001.737201		Plate flat coup square M5383 22 x 22 cm / 8.6 x 8.6 inch	6	001.742654
	Creamer 0,26 ltr. / 8.6 oz.	1	001.737204		Plate flat coup square M5383 16,5 x 16,5 cm / 6.5 x 6.5 inch	6	001.742653
	Mocha cup M5389 0,08 ltr. / 2.6 oz.	6	001.742665		Bowl coup square M5384 26 x 26 cm / 10.0 x 10.0 inch	4	001.742661
	Tea cup (LIFE) 0,14 ltr. / 4.6 oz.	6	001.737209		Bowl coup square M5384 22 x 22 cm / 8.6 x 8.6 inch	6	001.742660
	Coffee cup 0,19 ltr. / 6.3 oz.	6	001.742666		Bowl coup square M5384 17,5 x 17,5 cm / 6.8 x 6.8 inch	6	001.742659
	Cappuccino cup M5389 0,22 ltr. / 7.3 oz.	6	001.742667		Bowl coup square M5384 13 x 13 cm / 5.0 x 5.0 inch	6	001.742658
	Tea cup (LIFE) 0,28 ltr. / 9.3 oz.	6	001.737208		Plate flat coup rectangular M5385 35 x 20 cm / 14.0 x 8.0 inch	2	001.742657
	Milkcoffee cup M5389 0,35 ltr. / 11.6 oz.	6	001.742668		Bowl coup rectangular M5386 25,5 x 18 cm / 10.0 x 7.0 inch	2	001.742662
	Mug with handle M5389 0,28 ltr. / 9.3 oz.	6	001.742669		Platter coup rectangular M5388 38 x 14 cm / 15.0 x 6.6 inch	2	001.742663
	Mug with handle M5389 0,38 ltr. / 12.6 oz.	1	001.742670		Covered vegetable (LIFE) 3,00 ltr. / 100.0 oz.	1	001.737227
	Saucer square M5387 13 x 13 cm / 5.0 x 5.0 inch*	6	001.742671		Gravy boat (LIFE) 0,60 ltr. / 20.0 oz.	1	001.737230
	Saucer square M5387 16 x 16 cm / 6.3 x 6.3 inch**	6	001.742672		Egg cup with rest (LIFE)	6	001.737231
	Saucer round M5390 13,5 cm / 5.3 inch*	6	001.742673				
	Saucer round M5390 16,5 cm / 6.5 inch**	6	001.742674				
	Showplate flat M5380 33 cm / 13.0 inch	4	001.729476				
	Plate flat coup M5380 30 cm / 12.0 inch	6	001.729470				
	Plate flat coup M5380 28 cm / 11.0 inch	6	001.729469				
	Plate flat coup M5380 26 cm / 10.3 inch	6	001.729468				
	Plate flat coup M5380 21,5 cm / 8.5 inch	6	001.729467				
	Plate flat coup M5380 16,5 cm / 6.5 inch	6	001.729466				
	Bowl coup M5381 28 cm / 11.0 inch	4	001.729475				
	Bowl coup M5381 26 cm / 10.3 inch	6	001.729474				
	Bowl coup M5381 23 cm / 9.3 inch	6	001.729473				
	Bowl coup M5381 20 cm / 7.8 inch	6	001.729472				
	Bowl coup M5381 14,5 cm / 5.8 inch	6	001.729471				
	Platter coup M5379 33 x 18 cm / 13.0 x 7.0 inch	2	001.733789				
	Platter coup M5379 40 x 25,5 cm / 16.0 x 10.3 inch	2	001.729477				
	Platter coup M5379 43 x 19 cm / 17.3 x 7.5 inch	2	001.729478				
	Platter coup M5379 35 x 11 cm / 13.8 x 4.5 inch	2	001.733788				
	Platter coup M5379 44 x 14 cm / 17.3 x 5.6 inch	2	001.729479				
	Setplatter 44 cm / 17.5 x 5.6 inch	2	001.732630				
	Bowl high 0,18 ltr. / 6.3 oz.	6	001.732631				
	Bowl low 0,21 ltr. / 6.6 oz.	6	001.732632				

* suitable for mocha cup M5389 0,08 ltr. / 2.6 oz.,
tea cup (LIFE) 0,14 ltr. / 4.6 oz.

**suitable for all cups, except mocha cup M5389 0,08 ltr. / 2.6 oz.,
tea cup (LIFE) 0,14 ltr. / 4.6 oz.

¹ PU = Packing Unit

² Item-No refers to undecorated articles



SAVOY

ITEM DESCRIPTION	PU ¹	Item-No ²
Coffee pot 1 0,30 ltr. / 10.0 oz.	2	001.505082
Tea pot 1 0,40 ltr. / 13.3 oz.	2	001.505355
Tea pot 2 0,75 ltr. / 25.0 oz.	2	001.505628
Warming plate small	1	001.509840
Sugar bowl 2 0,25 ltr. / 8.3 oz.	1	001.506564
Sugar dish 8 cm / 3.2 inch	12	001.506447
Creamer 00 0,03 ltr. / 1.0 oz.	12	001.506837
Creamer 1 0,15 ltr. / 5.0 oz.	1	001.506954
Creamer 2 0,25 ltr. / 8.3 oz.	1	001.507071
Coffee cup 1 0,18 ltr. / 6.0 oz.	6	001.508787
Saucer 1 16,4 cm / 6.5 inch	6	001.508631
Mocha cup 0,09 ltr. / 3.0 oz.	12	001.508514
Saucer 14,5 cm / 5.7 inch	12	001.508358
Breakfast cup 0,36 ltr. / 12.0 oz.	6	001.509606
Saucer 1 16,4 cm / 6.5 inch	6	001.508631
Milkcoffee cup 0,22 ltr. / 7.3 oz.	6	001.509333
Saucer 1 16,4 cm / 6.5 inch	6	001.508631
Coffee cup non stackable 0,18 ltr. / 6.0 oz.	6	001.507968
Saucer 1 16,4 cm / 6.5 inch	6	001.508631
Mocha cup non stackable 0,09 ltr. / 3.0 oz.	12	001.508241
Saucer 14,5 cm / 5.7 inch	12	001.508358
Chocolate cup non stackable 0,22 ltr. / 7.7 oz.	6	001.507422
Saucer 1 16,4 cm / 6.5 inch	6	001.508631
Milkcoffee cup non stackable 0,37 ltr. / 12.3 oz.	6	001.507695
Saucer 1 16,4 cm / 6.5 inch	6	001.508631
Mug with handle 0,25 ltr. / 8.3 oz.	6	001.509723
Egg cup with rest	6	001.502742
Set salt and pepper	1	001.503600
Vase	2	001.509879
Candleholder	2	001.510230
Ash tray	4	001.510113
Party-spoon	6	001.510347
Bowl sloping 8,5 cm / 3.4 inch	6	001.498374
Bowl sloping 11 cm / 4.4 inch	6	001.498881
Bowl square 9 cm / 3.5 x 3.5 inch	6	001.498491
Bowl square 11 cm / 4.8 x 4.8 inch	6	001.498764

¹ PU = Packing Unit
² Item-No refers to undecorated articles

ITEM DESCRIPTION	PU ¹	Item-No ²
Plate flat with rim 34 cm / 13.4 inch	2	001.501143
Plate flat with rim 33 cm / 13.0 inch	6	001.497321
Plate flat with rim 30 cm / 12.0 inch	6	001.497165
Plate flat with rim 28 cm / 11.3 inch	6	001.497009
Plate flat with rim 26 cm / 10.4 inch	6	001.496853
Plate flat with rim 23 cm / 9.3 inch	6	001.496697
Plate flat with rim 21 cm / 8.5 inch	6	001.496541
Plate flat with rim 18 cm / 6.8 inch	6	001.496385
Plate flat with rim 16 cm / 6.5 inch	6	001.496307
Gourmetplate round 30 cm / 12.0 inch	2	001.500363
Gourmetplate round 27 cm / 10.6 inch	2	001.500519
Gourmetplate round 21 cm / 8.5 inch	6	001.501065
Gourmetplate round 18 cm / 7.3 inch	6	001.500987
Gourmetplate round 16 cm / 6.5 inch	6	001.500675
Gourmetplate round 12 cm / 4.8 inch	6	001.500831
Plate deep with rim 23 cm / 9.2 inch	6	001.497477
Salad plate deep 19 cm / 7.6 inch	6	001.500168
Soup cup 0,27 ltr. / 9.0 oz.	6	001.497789
Saucer 1 16,4 cm / 6.5 inch	6	001.508631
Eventbowl 5253 18 cm / 7.0 x 4.8 inch	4	001.697323
Tureen 2,90 ltr. / 96.7 oz.	1	001.501260
Gravy boat 0,35 ltr. / 11.7 oz.	2	001.501767
Gravy boat 0,15 ltr. / 5.0 oz.	4	001.502625
Butter pad 0,04 ltr. / 1.3 oz.	2	001.502508
Bowl round 12 cm / 4.7 inch	6	001.497906
Bowl round 14 cm / 5.5 inch	4	001.498062
Bowl round 17 cm / 6.6 inch	2	001.498218
Bowl round 20 cm / 7.8 inch	2	001.498608
Bowl round 22 cm / 8.5 inch	2	001.498998
Bowl round 24 cm / 9.3 inch	2	001.499154
Bowl round 13 cm / 5.2 inch	4	001.499934
Bowl round 15 cm / 6.0 inch	4	001.500051
Oval platter 28 cm / 11.0 x 7.6 inch	2	001.504458
Oval platter 32 cm / 12.8 x 8.7 inch	2	001.504614
Oval platter 36 cm / 14.6 x 10.0 inch	2	001.504770
Plate rectangular 36 x 14 cm / 14.2 x 5.5 inch	2	001.504146
Plate rectangular 30 x 14 cm / 11.8 x 5.5 inch	2	001.503990
Plate rectangular 23 x 14 cm / 9.1 x 5.5 inch	2	001.503834
Plate rectangular 16 x 12 cm / 6.3 x 4.7 inch	2	001.503678
Duo plate 26 cm / 10.6 x 6.0 inch	2	001.504926
Bowl square 14 cm / 5.7 x 5.7 inch	6	001.499310
Bowl square 17,5 cm / 7.0 x 7.0 inch	2	001.499466
Bowl square 22 cm / 8.7 x 8.7 inch	2	001.499622



ITEM DESCRIPTION	PU ¹	Item-No ²
Plate flat with rim square 32 cm / 12.8 x 12.8 inch	6	001.626331
Plate flat with rim square 28 cm / 11.3 x 11.3 inch	6	001.626327
Plate flat with rim square 22,5 cm / 9.0 x 9.0 inch	6	001.620703
Plate flat with rim square 17 cm / 6.5 x 6.5 inch	6	001.645154
Plate flat with rim square 24,5 cm / 9.7 x 9.7 inch	6	001.620765
Plate rectangular 40 x 27,5 cm / 15.7 x 10.7 inch	2	001.684445
Plate rectangular 35 x 24,5 cm / 13.9 x 9.6 inch	2	001.654875
Plate rectangular 29,5 x 20 cm / 11.7 x 7.8 inch	6	001.684443
Plate deep rectangular 27,5 x 20,5 cm / 11.0 x 8.0 inch	2	001.684519
Gourmet-plate deep square 27 cm / 10.7 x 10.7 inch	6	001.626336
Gourmet-plate deep square 20,5 cm / 8.1 x 8.1 inch	6	001.621075
Gourmet-plate deep square 15,5 cm / 6.1 x 6.1 inch	6	001.620951
Gourmet-plate deep square 12 cm / 4.7 x 4.7 inch	6	001.621013
Saucer square 1 16,4 cm / 6.5 x 6.5 inch*	6	001.621323
Saucer square 14 cm / 5.5 x 5.5 inch	12	001.621385



ADDITIONAL ITEMS

ITEM DESCRIPTION	PU ¹	Item-No ²
Plate flat JL 31,5 cm / 12.5 x 9.8 inch	6	001.620641
Plate flat JL 26,5 cm / 10.4 x 7.6 inch	6	001.620579
Dipbowl oval JL 9 cm / 4.5 x 3.5 inch	6	001.620889
Dipbowl oval JL 14 cm / 7.9 x 5.2 inch	6	001.620827



* Combi-saucer

¹ PU = Packing Unit

² Item-No refers to undecorated articles



Additional, easy to match
undecorated articles can be purchased.



SAVOY

»GRAND BLUE« 57513

ITEM DESCRIPTION	PU ¹	Item-No
Plate flat with rim 34 cm / 13.4 inch	2	001.749573
Plate flat with rim 30 cm / 12.0 inch	6	001.749574
Plate flat with rim 28 cm / 11.3 inch	6	001.749575
Plate flat with rim 26 cm / 10.4 inch	6	001.749576
Plate flat with rim 21 cm / 8.5 inch	6	001.749577
Plate flat with rim 16 cm / 6.5 inch	6	001.749578
Gourmetplate round 27 cm / 10.6 inch	2	001.749579
Gourmetplate round 21 cm / 8.5 inch	6	001.749580

ITEM DESCRIPTION	PU ¹	Item-No
Plate deep with rim 23 cm / 9.2 inch	6	001.749581
Salad plate deep 19 cm / 7.6 inch	6	001.749582
Plate rectangular 35 x 24,5 cm / 13.9 x 9.6 inch	2	001.749583
Plate rectangular 29,5 x 20 cm / 11.7 x 7.8 inch	6	001.749584
Saucer 1 16,4 cm / 6.5 inch	6	001.749571
Saucer 14,5 cm / 5.7 inch	12	001.749572



¹ PU = Packing Unit



ITEM DESCRIPTION	PU ¹	Item-No ²
Coffee pot 1 0,35 ltr. / 11.7 oz.	2	001.681319
Tea pot 1 0,45 ltr. / 15.0 oz.	2	001.681320
Warming plate 1069 small	1	001.681347
Tea strainer (ACCESSOIRE)	2	001.750850
Rest for tea strainer	6	001.686022
Sugar bowl 2 0,25 ltr. / 8.3 oz.	1	001.681223
Sugar dish 8 cm / 3.1 inch	12	001.684448
Creamer 1 0,15 ltr. / 5.0 oz.	1	001.681326
Creamer 2 0,25 ltr. / 8.3 oz.	1	001.681224
Mocha cup 0,09 ltr. / 3.0 oz.	12	001.681339
Saucer oval 15,5 x 14 cm / 6.1 x 5.5 inch	6	001.681762
Saucer round 13,7 cm / 5.4 inch	12	001.681227
Coffee cup 1 0,18 ltr. / 6.0 oz.	6	001.681342
Milkcoffee cup 0,25 ltr. / 8.3 oz.	6	001.681231
Mug with handle stackable 0,28 ltr. / 9.3 oz.	6	001.681232
Combi saucer oval 1 17,8 x 16,2 cm / 7.0 x 6.4 inch	6	001.681230
Combi saucer round 1 16 cm / 6.3 inch	6	001.681229
Mocha cup 0,09 ltr. / 3.0 oz.	12	001.681225
Coffee cup 0,18 ltr. / 6.0 oz.	6	001.681336
Chocolate cup 0,25 ltr. / 8.3 oz.	6	001.681226
Milkcoffee cup 0,37 ltr. / 12.3 oz.	6	001.681337
Mug with handle 0,28 ltr. / 9.3 oz.	6	001.681346
Egg cup with rest	6	001.686025
Set salt and pepper	1	001.681313
Plate flat oval 18 cm / 7.0 x 6.4 inch	6	001.681214
Plate flat oval 24 cm / 9.4 x 8.5 inch	6	001.681215
Plate flat oval 30 cm / 11.7 x 10.6 inch	6	001.681216
Plate flat oval 34 cm / 13.5 x 12.1 inch	6	001.681217
Plate flat oval 37,5 cm / 14.9 x 13.4 inch	2	001.681752

ITEM DESCRIPTION	PU ¹	Item-No ²
Plate deep oval 25 cm / 9.8 x 9.2 inch	6	001.681218
Plate flat round 16 cm / 6.2 inch	6	001.681210
Plate flat round 23 cm / 9.0 inch	6	001.681211
Plate flat round 26 cm / 10.3 inch	6	001.681751
Plate flat round 28 cm / 11.0 inch	6	001.681212
Plate flat round 30 cm / 11.7 inch	6	001.681213
Gourmet plate round 23 cm / 9.0 inch	6	001.681220
Gourmet plate round 27 cm / 10.6 inch	2	001.681761
Pasta plate deep round 26,5 cm / 10.4 inch	6	001.722893
Soup cup 0,27 ltr. / 9.0 oz.	6	001.681177
Saucer 1 oval 17,8 x 16,2 cm / 7.0 x 6.4 inch	6	001.681230
Saucer 1 round 16 cm / 6.3 inch	6	001.681229
Gravy boat 0,50 ltr. / 16.7 oz.	2	001.681306
Gravy boat 0,15 ltr. / 5.0 oz.	4	001.681309
Bowl oval 15 cm / 6.0 x 5.6 inch	6	001.683169
Bowl oval 17 cm / 6.6 x 6.1 inch	4	001.683170
Bowl oval 20 cm / 7.8 x 7.3 inch	2	001.681759
Bowl oval 24 cm / 9.4 x 8.7 inch	2	001.681760
Oval plate flat 28 cm / 11.0 x 8.2 inch	2	001.683768
Oval plate flat 31 cm / 12.2 x 9.1 inch	2	001.681221
Oval plate flat 35 cm / 13.7 x 8.7 inch	2	001.681222
Bowl 21 cm / 8.3 inch	2	001.683167



¹ PU = Packing Unit
² Item-No refers to undecorated articles



ITEM DESCRIPTION	PU ¹	Item-No ²
Eventplate flat oval 25 cm / 9.9 x 9.0 inch	6	001.681754
Eventplate deep oval 22 cm / 8.8 x 7.8 inch	4	001.681757
Eventplate deep oval 25 cm / 10.4 x 9.4 inch	2	001.681758
Eventplate deep round 26 cm / 10.2 inch	2	001.681755
Eventbowl 8,5 cm / 3.3 inch	6	001.685643
Eventbowl 10,5 cm / 4.1 inch	6	001.685644
Eventbowl 16 cm / 6.3 inch	4	001.685645
Eventbowl 21 cm / 7.9 inch	2	001.685646
Eventspoon 12 cm	6	001.685654
Eventspoon 18 cm	4	001.685655
Eventbowl sloping 14 cm / 5.6 inch	6	001.685648
Eventbowl sloping 18 cm / 7.2 inch	4	001.685650
Eventbowl sloping 22 cm / 8.7 inch	2	001.685651



¹ PU = Packing Unit
² Item-No refers to undecorated articles



C

OFFE-E-MOTION

	ITEM DESCRIPTION	PU ¹	Item-No ²
	Creamer M5341 0,25 ltr. / 8.3 oz.	1	001.718472
	Sugar bowl with cover M5342 0,26 ltr. / 8.7 oz.	1	001.718469
	Mocha cup M5352 0,09 ltr. / 3.0 oz.	6	001.718477
	Coffee cup M5344 0,18 ltr. / 6.0 oz.	6	001.718476
	Cappuccino cup M5345 0,26 ltr. / 8.7 oz.	6	001.718482
	Milkcoffee cup M5347 0,38 ltr. / 12.7 oz.	6	001.718480
	Mug with handle M5348 0,30 ltr. / 10.0 oz.	6	001.718483
	Mug with handle M5349 0,45 ltr. / 15.0 oz.	1	001.718484
	Coffee cup low M5364 0,18 ltr. / 6.0 oz.	6	001.720153
	Cappuccino cup low M5346 0,25 ltr. / 8.0 oz.	6	001.718481
	Milkcoffee cup low M5365 0,37 ltr. / 12.3 oz.	6	001.720154
	Saucer small M5354 17,5 cm / 6.8 x 5.7 inch*	6	001.718474
	Saucer large M5350 22 cm / 8.7 x 7.3 inch**	6	001.718473

	ITEM DESCRIPTION	PU ¹	Item-No ²
	Plate flat M5363 22 cm / 8.7 x 7.7 inch	6	001.720152
	Plate flat M5351 25,5 cm / 10.0 x 9.0 inch	6	001.718462
	Plate flat M5355 29 cm / 11.5 x 10.5 inch	6	001.718463
	Plate flat M5356 33,5 cm / 13.2 x 11.7 inch	6	001.718464
	Bowl round M5357 15 cm / 6.0 x 5.0 inch	2	001.718465
	Bowl round M5358 20 cm / 8.0 x 6.9 inch	1	001.718466
	Bowl round M5359 25 cm / 9.8 x 8.5 inch	1	001.718467
	Bowl round M5360 0,50 ltr. / 18.3 oz.****	1	001.718485
	Saucer round M5361 small 12,5 cm / 5.0 inch***	6	001.718478
	Saucer round M5362 big 17,5 cm / 6.9 inch**	6	001.718479



¹ PU = Packing Unit
² Item-No refers to undecorated articles

* suitable for all cups
 ** suitable for coffee cup M5433 0,18 ltr. / 6.0 oz.
 cappuccino cup M5345 0,25 ltr. / 8.7 oz.
 milkcoffee cup M5347 0,37 ltr. / 12.7 oz.
 mug with handle M5348 0,30 ltr. / 10.0 oz.
 mug with handle M5349 0,35 ltr. / 15.0 oz.
 coffee cup low M5364 0,18 ltr. / 6.0 oz.
 cappuccino cup low M5346 0,25 ltr. / 8.0 oz.
 milkcoffee cup low M5365 0,37 ltr. / 12.3 oz.
 *** suitable for mocha cup M5352 0,09 ltr. / 3.0 oz.
 **** suitable for round M5362 large 17,5 cm / 6.9 inch



L AGUNA

	ITEM DESCRIPTION	PU ¹	Item-No ²
	Coffee pot 1 0,30 ltr. / 10.0 oz.	2	001.698919
	Tea pot 1 0,32 ltr. / 10.7 oz.	2	001.698922
	Sugar bowl 2 0,25 ltr. / 8.3 oz.	1	001.698925
	Creamer 2 0,24 ltr. / 8.0 oz.	1	001.698928
	Coffee cup 1 0,18 ltr. / 6.0 oz.	6	001.698946
	Saucer 1 16 cm / 6.3 inch	6	001.698945
	Mocha cup 0,09 ltr. / 3.0 oz.	12	001.698943
	Saucer 13,4 cm / 5.3 inch	12	001.698942
	Milkcoffee cup 0,22 ltr. / 7.3 oz.	6	001.698949
	Saucer 1 16 cm / 6.3 inch	6	001.698945
	Coffee cup non stackable 0,18 ltr. / 6.0 oz.	6	001.698937
	Saucer 1 16 cm / 6.3 inch	6	001.698945
	Chocolate cup non stackable 0,22 ltr. / 7.3 oz.	6	001.698931
	Saucer 1 16 cm / 6.3 inch	6	001.698945
	Egg cup with rest	6	001.702210
	Set salt and pepper	1	001.702212
	Mug with handle 0,25 ltr. / 8.3 oz.	6	001.698950

	ITEM DESCRIPTION	PU ¹	Item-No ²
	Plate flat with rim 33 cm / 13.0 inch	6	001.698899
	Plate flat with rim 30 cm / 12.0 inch	6	001.698898
	Plate flat with rim 28 cm / 11.0 inch	6	001.698897
	Plate flat with rim 26 cm / 10.3 inch	6	001.698896
	Plate flat with rim 23 cm / 9.0 inch	6	001.698895
	Plate flat with rim 21 cm / 8.5 inch	6	001.698894
	Plate flat with rim 17 cm / 6.6 inch	6	001.698893
	Pasta bowl deep 30 cm / 12.0 inch	2	001.698910
	Pasta bowl deep 27 cm / 10.6 inch	2	001.698911
	Soup plate with rim 23 cm / 9.1 inch	6	001.698900
	Salad plate deep 19 cm / 7.4 inch	6	001.698909
	Cupsoup 19 cm / 7.4 inch	6	001.698901
	Soup cup 0,27 ltr. / 9.0 oz.	6	001.698904
	Saucer 1 16 cm / 6.3 inch	6	001.698945
	Gravy boat 0,50 ltr. / 16.7 oz.	2	001.702211
	Gravy boat 0,15 ltr. / 5.0 oz.	4	001.698912
	Bowl round 15 cm / 6.0 inch	4	001.698905
	Bowl round 18 cm / 7.0 inch	2	001.698906
	Bowl round 20 cm / 8.0 inch	2	001.698907
	Bowl round 23 cm / 9.0 inch	2	001.698908
	Oval platter 28 cm / 11.0 x 8.1 inch	2	001.698915
	Oval platter 31 cm / 12.1 x 9.2 inch	2	001.698916
	Oval platter 35 cm / 13.6 x 10.4 inch	2	001.698917
	Soupbowl 0,50 ltr. / 16.7 oz.	6	001.706009
	Plate flat 25,5 cm / 10.0 inch	6	001.706010



¹ PU = Packing Unit
² Item-No refers to undecorated articles



LUXOR

FINE CREAM

ITEM DESCRIPTION	PU ¹	Item-No ²
Coffee pot 1 0,30 ltr. / 10.0 oz.	2	001.522974
Tea pot 1 0,32 ltr. / 10.7 oz.	2	001.523415
Sugar bowl 2 0,25 ltr. / 8.3 oz.	1	001.523918
Creamer 00 0,03 ltr. / 1.0 oz.	12	001.524171
Creamer 1 0,15 ltr. / 5.0 oz.	1	001.524360
Creamer 2 0,25 ltr. / 8.0 oz.	1	001.524549
Coffee pot 1 0,18 ltr. / 6.0 oz.	6	001.527826
Saucer 1 16 cm / 6.3 inch	6	001.527450
Mocha cup 0,09 ltr. / 3.0 oz.	12	001.527132
Saucer 13,4 cm / 5.3 inch	12	001.526819
Milkcoffee cup 0,22 ltr. / 7.3 oz.	6	001.528896
Saucer 1 16 cm / 6.3 inch	6	001.527450
Coffee cup non stackable 0,18 ltr. / 6.0 oz.	6	001.526123
Saucer 1 16 cm / 6.3 inch	6	001.527450
Mocha cup non stackable 0,09 ltr. / 3.0 oz.	12	001.526564
Saucer 13,4 cm / 5.3 inch	12	001.526819
Chocolate cup non stackable 0,22 ltr. / 7.3 oz.	6	001.525179
Saucer 1 16 cm / 6.3 inch	6	001.527450
Milkcoffee cup non stackable 0,37 ltr. / 12.3 oz.	6	001.525682
Saucer 1 16 cm / 6.3 inch	6	001.527450
Egg cup with rest	6	001.520833
Set salt and pepper	1	001.521587
Mug with handle 0,25 ltr. / 8.3 oz.	6	001.529526

ITEM DESCRIPTION	PU ¹	Item-No ²
Plate flat with rim 33 cm / 12.9 inch	6	001.516108
Plate flat with rim 30 cm / 11.9 inch	6	001.515856
Plate flat with rim 28 cm / 11.1 inch	6	001.515480
Plate flat with rim 26 cm / 10.3 inch	6	001.515102
Plate flat with rim 23 cm / 9.1 inch	6	001.621448
Plate flat with rim 21 cm / 8.5 inch	6	001.514724
Plate flat with rim 17 cm / 6.6 inch	6	001.514346
Pasta bowl deep 30 cm / 11.9 inch	2	001.519446
Pasta bowl deep 27 cm / 10.6 inch	2	001.519636
Soup plate with rim 23 cm / 9.1 inch	6	001.516361
Salad plate deep 19 cm / 7.4 inch	6	001.519195
Coupsoup 19 cm / 7.5 inch	6	001.516674
Soup cup 0,27 ltr. / 9.0 oz.	6	001.517240
Saucer 1 16 cm / 6.3 inch	6	001.527450
Gravy boat 0,50 ltr. / 16.7 oz.	2	001.520265
Gravy boat 0,09 ltr. / 3.0 oz.	4	001.637394
Gravy boat 0,15 ltr. / 5.0 oz.	4	001.520643
Butter pad 0,05 ltr. / 1.7 oz.	2	001.520454
Bowl round 15 cm / 5.9 inch	4	001.517432
Bowl round 18 cm / 7.0 inch	2	001.517746
Bowl round 20 cm / 7.9 inch	2	001.517998
Bowl round 23 cm / 9.0 inch	2	001.518251
Bowl round 25 cm / 9.7 inch	2	001.518565
Oval platter 28 cm / 10.9 x 8.1 inch	2	001.521904
Oval platter 31 cm / 12.1 x 9.2 inch	2	001.522157
Oval platter 35 cm / 13.6 x 10.4 inch	2	001.522471
Plate flat 25,5 cm / 9.9 inch	6	001.594342

¹ PU = Packing Unit
² Item-No refers to undecorated articles



ITEM DESCRIPTION	PU ¹	Item-No ²
Coffee pot 1 0,36 ltr. / 12.0 oz.	2	001.173551
Tea pot 1 0,32 ltr. / 10.7 oz.	2	001.174553
Sugar bowl 2 0,23 ltr. / 7.7 oz.	1	001.175238
Sugar dish 8 cm / 3.2 inch	12	001.175066
Creamer 00 0,02 ltr. / 0.7 oz.	12	001.175911
Creamer 1 0,15 ltr. / 5.0 oz.	1	001.176231
Creamer 2 0,23 ltr. / 7.7 oz.	1	001.176561
Espresso cup 5012 0,09 ltr. / 3.0 oz.	6	001.177213
Saucer 5012 12 cm / 4.7 inch	6	001.176734
Cup 5115 0,14 ltr. / 4.7 oz.	6	001.185818
Saucer 5115 13 cm / 5.3 inch	6	001.185647
Cup 5089 0,25 ltr. / 7.7 oz.	6	001.184484
Saucer 5089 14,7 cm / 5.8 inch	6	001.183983
Cup 5092 0,35 ltr. / 12.0 oz.	6	001.185156
Saucer 5092 14,7 cm / 6.3 inch	6	001.184815



¹ PU = Packing Unit
² Item-No refers to undecorated articles

ITEM DESCRIPTION	PU ¹	Item-No ²
Espresso cup 1132 0,09 ltr. / 3.0 oz.	6	001.178516
Saucer 1132 11,8 cm / 4.6 inch	6	001.177855
Cup 1163 0,18 ltr. / 6.0 oz.	6	001.188318
Saucer 1163 14,7 cm / 5.8 inch	6	001.187817
Cappuccino cup 1131 0,22 ltr. / 7.3 oz.	6	001.186971
Saucer 1131 14,7 cm / 5.8 inch	6	001.186312
Cup 5118 0,29 ltr. / 9.7 oz.	6	001.658838
Saucer 5118 15,9 cm / 6.3 inch	6	001.658837
Cup 1164 0,37 ltr. / 12.3 oz.	6	001.189312
Saucer 1164 15,9 cm / 6.3 inch	6	001.188651
Cup 5041 0,50 ltr. / 16.7 oz.	6	001.185487
Saucer 5041 19,1 cm / 7.5 inch	6	001.185327
Cup without handle 5041 0,50 ltr. / 16.7 oz.	6	001.185989
Mug with handle 5005 0,25 ltr. / 8.3 oz.	6	001.190944
Mug with handle 05 0,26 ltr. / 8.7 oz.	6	001.189972
Mug with handle 08 0,31 ltr. / 10.3 oz.	6	001.190132
Mug with handle 0,25 ltr. / 8.3 oz.	6	001.189812
Coffee cup 1 0,18 ltr. / 6.0 oz.	6	001.181815
Saucer 1 16,2 cm / 6.4 inch	6	001.181154
Coffee cup 2 0,16 ltr. / 5.3 oz.	6	001.182624
Saucer 2 13,7 cm / 5.4 inch	6	001.182305
Coffee cup 3 0,20 ltr. / 6.7 oz.	6	001.187484
Saucer 1 16,2 cm / 6.4 inch	6	001.181154
Chocolate cup 0,23 ltr. / 7.3 oz.	6	001.190624
Saucer 1 16,2 cm / 6.4 inch	6	001.181154
Mocha cup 0,09 ltr. / 3.0 oz.	12	001.180662
Saucer 13,6 cm / 5.4 inch	12	001.180001
Mocha cup high 0,08 ltr. / 2.7 oz.	12	001.179838
Saucer 13,6 cm / 5.4 inch	12	001.180001
Milkcoffee cup 0,25 ltr. / 8.3 oz.	6	001.183298
Saucer 1 16,2 cm / 6.4 inch	6	001.181154



MERAN

BASIC

ITEM DESCRIPTION	PU ¹	Item-No ²
Plate flat with rim 33 cm / 13.0 inch	6	001.157857
Plate flat with rim 30 cm / 12.0 inch	6	001.157014
Plate flat with rim 28 cm / 11.0 inch	6	001.156022
Plate flat with rim 26 cm / 10.2 inch	6	001.155188
Plate flat with rim 23 cm / 9.0 inch	6	001.154854
Plate flat with rim 20 cm / 8.0 inch	6	001.154013
Plate flat with rim 17 cm / 6.8 inch	6	001.153180
Plate flat with rim 15 cm / 6.0 inch	6	001.690815
Plate deep with rim 23 cm / 8.9 inch	6	001.160941
Pasta plate oval 32 cm / 12.6 x 10.3 inch	1	001.166267
Pasta plate 5009 30 cm / 11.8 inch	2	001.167730
Pasta plate 5064 27 cm / 10.6 inch	2	001.167068
Pasta plate 5008 23 cm / 9.0 inch	6	001.167388
Salad plate 19 cm / 7.6 inch	6	001.166589
Tureen 3,00 ltr. / 100.0 oz.	1	001.168093
Soup cup 0,28 ltr. / 9.3 oz.	6	001.162264
Saucer 1 16,2 cm / 6.4 inch	6	001.181154
Gravy boat 0,40 ltr. / 13.3 oz.	2	001.168255
Butter pad 0,04 ltr. / 1.3 oz.	2	001.168894
Gravy boat 0,10 ltr. / 3.3 oz.	4	001.169226

ITEM DESCRIPTION	PU ¹	Item-No ²
Bowl round 13 cm / 5.0 inch	6	001.162949
Bowl round 15 cm / 5.8 inch	4	001.163610
Bowl round 16 cm / 6.3 inch	2	001.164123
Bowl round 20 cm / 7.9 inch	2	001.164637
Bowl round 23 cm / 9.0 inch	2	001.165287
Bowl round 25 cm / 10.0 inch	2	001.165778
Oval plate flat 25 cm / 10.0 x 6.4 inch	2	001.171554
Oval plate flat 28 cm / 11.0 x 8.3 inch	2	001.172056
Oval plate flat 31 cm / 12.2 x 9.1 inch	2	001.172547
Oval plate flat 35 cm / 13.8 x 10.6 inch	2	001.173049
Vase	4	001.193048
Candleholder	2	001.194062
Ash tray	4	001.193730
Set salt and pepper	1	001.171063
Egg cup with rest	6	001.169716



¹ PU = Packing Unit
² Item-No refers to undecorated articles



MERAN

STEAK & MORE

ITEM DESCRIPTION	PU ¹	Item-No ²
Coup plate flat oval 5234 21 cm / 8.3 x 7.6 inch	6	001.004414
Coup plate flat oval 5195 25 cm / 9.8 x 9.0 inch	6	001.160460
Coup plate flat oval 5293 27 cm / 10.6 x 9.7 inch	6	001.159980
Coup plate flat oval 5192 29 cm / 11.9 x 11.0 inch	6	001.159500
Coup plate flat oval 5235 34 cm / 13.4 x 12.0 inch	2	001.004415
Fitness plate 5248 34 cm / 13.4 x 12.0 inch	2	001.659439
Fitness plate 5258 34 cm / 13.4 x 12.0 inch	2	001.705925
Coup plate flat 5196 15,5 cm / 6.2 inch	6	001.158540
Coup plate flat 5197 17,5 cm / 7.0 inch	6	001.159020
Coup plate flat round 5208 21,5 cm / 8.5 inch	6	001.618397
Coup plate flat round 5209 25,5 cm / 10.0 inch	6	001.618586
Coup plate flat round 5210 29 cm / 11.5 inch	6	001.618775
Coup plate deep 5236 14,5 cm / 5.7 inch	6	001.004416
Coup plate deep 5237 23 cm / 9.0 inch	6	001.004417
Coup plate deep 5211 29 cm / 11.6 inch	6	001.618964

ITEM DESCRIPTION	PU ¹	Item-No ²
Bowl 1060 0,60 ltr. / 20.0 oz.	6	001.004428
Bowl oval M5307 9 cm / 3.3 x 2.6 inch	6	001.722208
Bowl oval M5306 12 cm / 4.7 x 3.7 inch	6	001.722213
Soup bowl oval 5238 16 cm / 6.0 x 5.3 inch	4	001.004418
Bowl oval 5239 21 cm / 8.3 x 7.0 inch	2	001.004419
Bowl oval 5240 25,5 cm / 10.0 x 8.5 inch	2	001.004420
Oval platter deep 5231 18,5 cm / 7.2 x 4.7 inch	2	001.708948
Oval platter 5230 23,5 cm / 9.3 x 6.0 inch	2	001.708947
Espresso cup 5241 0,09 ltr. / 3.0 oz.	6	001.004427
Saucer 5241 12,7 cm / 5.0 inch	6	001.004426
Coffee cup 5242 0,20 ltr. / 6.7 oz.	6	001.004425
Saucer 5242/5243 16,2 cm / 6.4 inch	6	001.004424
Cappuccino cup 5243 0,25 ltr. / 8.3 oz.	6	001.004423
Saucer 5242/5243 16,2 cm / 6.4 inch	6	001.004424
Mug Diva 5156 0,35 ltr. / 13.3 oz.	6	001.004429
Saucer 5156 17,5 cm / 7.0 inch	6	001.004421



¹ PU = Packing Unit
² Item-No refers to undecorated articles



	ITEM DESCRIPTION	PU ¹	Item-No ²
	Gourmet-plate flat organic M5340 34 cm / 13.4 x 11.0 inch	2	001.725323
	Gourmet-plate flat organic M5318 29,5 cm / 11.5 x 9.3 inch	6	001.725322
	Gourmet-plate flat organic M5319 24 cm / 9.4 x 7.7 inch	6	001.725321
	Gourmet-plate flat organic M5339 19 cm / 7.5 x 6.5 inch	6	001.725320
	Gourmet-bowl deep organic M5317 26 cm / 9.8 x 8.7 inch	2	001.725328
	Gourmet-bowl deep organic M5316 20 cm / 7.7 x 6.4 inch	2	001.725327
	Gourmet-bowl deep organic M5374 16 cm / 6.2 x 5.4 inch	4	001.725326
	Gourmet-bowl deep organic M5373 12 cm / 4.8 x 4.0 inch	6	001.725325
	Gourmet-bowl deep organic M5372 8 cm / 3.4 x 2.7 inch	6	001.725324

	ITEM DESCRIPTION	PU ¹	Item-No ²
	Coffee cup organic 0,21 ltr. / 7.0 oz.	6	001.725333
	Cappuccino cup organic 0,28 ltr. / 9.5 oz.	6	001.725334
	Milkcoffee cup organic 0,37 ltr. / 12.3 oz.	6	001.725335
	Tea cup organic 0,22 ltr. / 7.3 oz.	6	001.725336
	Mug with handle organic 0,33 ltr. / 10.7 oz.	6	001.725341
	Saucer organic M5375 19 cm / 7.5 x 6.5 inch	6	001.725340
	Mocha cup organic 0,11 ltr. / 3.7 oz.	6	001.725337
	Tea cup organic 0,16 ltr. / 5.3 oz.	6	001.725338
	Saucer organic M5376 15 cm / 6.0 x 5.2 inch	6	001.725339
	Sugar bowl with lid organic M5342 0,25 ltr. / 8.3 oz.	1	001.725329
	Creamer organic M5341 0,25 ltr. / 8.3 oz.	1	001.725332



¹ PU = Packing Unit
² Item-No refers to undecorated articles



	ITEM DESCRIPTION	PU ¹	Item-No ²
	Coffee pot 1,20 ltr. / 40.7 oz.	1	001.015914
	Sugar bowl 0,28 ltr. / 9.3 oz.	1	001.015915
	Creamer 0,25 ltr. / 8.3 oz.	1	001.015916
	Coffee cup 0,22 ltr. / 7.3 oz.	6	001.015918
	Cappuccino cup 0,23 ltr. / 8.3 oz.	6	001.015923
	Milk coffee cup 0,37 ltr. / 12.3 oz.	6	001.015922
	Saucer round 17 cm / 6.7 inch	6	001.015927
	Saucer square 19,5 x 16,5 cm / 7.8 x 6.5 inch	6	001.015928
	Mocha cup 0,09 ltr. / 3.0 oz.	6	001.015921
	Saucer round 14,5 cm / 5.7 inch	6	001.015925
	Saucer square 16 x 13,5 cm / 6.3 x 5.3 inch	6	001.015926
	Mug with handle 0,34 ltr. / 11.3 oz.	6	001.015924
	Egg cup with rest	6	001.015909
	Espresso cup 5241 0,09 ltr. / 3.0 oz.	6	001.659437
	Coffee cup 5242 0,20 ltr. / 6.7 oz.	6	001.659436
	Cappuccino cup 5243 0,25 ltr. / 8.3 oz.	6	001.659435
	Saucer square Hotel 19,5 cm / 7.8 x 6.5 inch	6	001.659434
	Saucer square Hotel 16,0 cm / 6.3 x 5.3 inch	6	001.659433

	ITEM DESCRIPTION	PU ¹	Item-No ²
	Plate flat square 34,5 x 30 cm / 13.6 x 12.0 inch	2	001.015899
	Plate flat square 30 x 26 cm / 11.7 x 10.3 inch	6	001.015900
	Plate flat square 25 x 21 cm / 10.0 x 8.4 inch	6	001.015898
	Plate flat square 20 x 16,5 cm / 7.8 x 6.5 inch	6	001.680985
	Bowl square 27 x 23 cm / 10.6 x 9.0 inch	1	001.685522
	Bowl square 23,5 cm / 9.3 x 8.0 inch	1	001.685521
	Bowl square 19,5 x 17 cm / 7.8 x 6.7 inch	1	001.685520
	Plate flat 33,5 cm / 13.2 inch	1	001.015893
	Plate flat 28 cm / 11.0 inch	6	001.015894
	Plate flat 23 cm / 9.0 inch	6	001.015897
	Plate flat 20 cm / 7.9 inch	6	001.015896
	Pasta plate deep 27 cm / 10.7 inch	2	001.015906
	Plate deep 22,5 cm / 9.0 inch	6	001.015895
	Bowl round 19 cm / 7.4 inch	6	001.015901
	Plate 35 x 26 cm / 13.8 x 10.4 inch	1	001.015912
	Plate 32 x 26,5 cm / 12.5 x 10.4 inch	1	001.015911
	Bowl round 30,5 cm / 12.0 inch	1	001.015905
	Bowl round 25 cm / 10.0 inch	1	001.015904
	Bowl round 20 cm / 8.0 inch	1	001.015903
	Bowl round 15 cm / 6.0 inch	2	001.015902
	Tureen with lid 3,0 ltr. / 102.0 oz.	1	001.015907
	Gravy boat 0,55 ltr. / 18.3 oz.	1	001.015908



¹ PU = Packing Unit
² Item-No refers to undecorated articles



SALZBURG

	ITEM DESCRIPTION	PU ¹	Item-No ²
	Coffee pot 1 0,34 ltr. / 11.3 oz.	2	001.606690
	Coffee pot 3 0,66 ltr. / 22.0 oz.	2	001.607216
	Tea pot 1 0,33 ltr. / 11.0 oz.	2	001.607901
	Sugar bowl 2 0,20 ltr. / 6.7 oz.	1	001.608802
	Sugar dish 8 cm / 3.2 inch	12	001.608485
	Creamer 0 0,04 ltr. / 1.3 oz.	12	001.609394
	Creamer 1 0,15 ltr. / 5.0 oz.	1	001.609538
	Creamer 2 0,23 ltr. / 7.7 oz.	1	001.609754
	Coffee cup 1 0,18 ltr. / 6.0 oz.	6	001.611113
	Saucer 1 14,5 cm / 5.7 inch	6	001.610860
	Chocolate cup non stackable 0,22 ltr. / 7.3 oz.	6	001.613610
	Saucer 1 14,5 cm / 5.7 inch	6	001.610860
	Mocha cup 0,09 ltr. / 3.0 oz.	12	001.610585
	Saucer 12 cm / 4.7 inch	12	001.610333
	Milkcoffee cup 0,25 ltr. / 8.3 oz.	6	001.612504
	Saucer 1 14,5 cm / 5.7 inch	6	001.610860
	Egg cup with rest	6	001.604695
	Set salt and pepper	1	001.605538
	Mug with handle 06 0,25 ltr. / 8.3 oz.	12	001.613256

	ITEM DESCRIPTION	PU ¹	Item-No ²
	Sugar packed holder	6	001.608773
	Plate flat with rim 30 cm / 12.0 inch	6	001.600942
	Plate flat with rim 27 cm / 10.5 inch	6	001.600653
	Plate flat with rim 25 cm / 9.8 inch	6	001.600365
	Plate flat with rim 21 cm / 8.3 inch	6	001.600047
	Plate flat with rim 19 cm / 7.5 inch	6	001.599759
	Plate flat with rim 17 cm / 6.7 inch	6	001.599434
	Plate flat with rim 15 cm / 6.0 inch	6	001.599318
	Plate deep 23 cm / 9.0 inch	6	001.601325
	Salad plate 19 cm / 7.5 inch	6	001.603822
	Coupesoup 19 cm / 7.5 inch	6	001.601607
	Pasta plate deep 30 cm / 11.9 inch	2	001.604031
	Soup cup 0,28 ltr. / 9.3 oz.	6	001.602242
	Saucer 16,2 cm / 6.4 inch	6	001.601953
	Tureen 3,00 ltr. / 100.0 oz.	1	001.604126
	Gravy boat 0,55 ltr. / 18.3 oz.	2	001.604270
	Gravy boat 0,10 ltr. / 3.3 oz.	4	001.604515
	Butter pad 0,06 ltr. / 2.0 oz.	2	001.604450
	Bowl round 13 cm / 5.0 inch	6	001.602488
	Bowl round 15 cm / 6.0 inch	4	001.602669
	Bowl round 18 cm / 7.0 inch	2	001.602921
	Bowl round 20 cm / 8.0 inch	2	001.603138
	Bowl round 23 cm / 9.0 inch	2	001.603390
	Bowl round 25 cm / 9.8 inch	2	001.603606
	Oval platter 28 cm / 11.0 x 7.0 inch	2	001.605718
	Oval platter 31 cm / 12.5 x 8.4 inch	2	001.605970
	Oval platter 35 cm / 14.0 x 9.5 inch	2	001.606215
	Oval platter 38 cm / 15.0 x 10.4 inch	2	001.606467
	Oval platter 24 cm / 9.5 x 5.6 inch	2	001.604911
	Candleholder 941	2	001.616203

¹ PU = Packing Unit
² Item-No refers to undecorated articles



MARIENBAD

DISCONTINUED AFTER 03/2021

ITEM DESCRIPTION	PU ¹	Item-No ²
Coffee pot 1 0,35 ltr. / 11.7 oz.	2	001.539906
Tea pot 1 0,35 ltr. / 11.7 oz.	2	001.540481
Sugar bowl 2 0,23 ltr. / 7.7 oz.	1	001.540795
Sugar dish 9 cm / 3.5 inch	12	001.540650
Creamer 1 0,16 ltr. / 5.3 oz.	1	001.541154
Coffee cup 1 0,18 ltr. / 6.0 oz.	6	001.541945
Saucer 1 15 cm / 6.0 inch	6	001.541802
Chocolate cup 0,23 ltr. / 7.3 oz.	6	001.543407
Saucer 1 15 cm / 6.0 inch	6	001.541802
Mocha cup 0,09 ltr. / 3.0 oz.	12	001.541679
Saucer 12 cm / 4.8 inch	12	001.541584
Milkcoffee cup 0,25 ltr. / 8.3 oz.	6	001.542497
Saucer 1 15 cm / 6.0 inch	6	001.541802
Set salt and pepper	1	001.539326
Mug with handle 0,30 ltr. / 10.0 oz.	6	001.543168

ITEM DESCRIPTION	PU ¹	Item-No ²
Plate flat with rim 30 cm / 12.0 inch	6	001.537146
Plate flat with rim 27 cm / 10.6 inch	6	001.537002
Plate flat with rim 25 cm / 9.9 inch	6	001.536858
Plate flat with rim 21 cm / 8.2 inch	6	001.536714
Plate flat with rim 19 cm / 7.5 inch	6	001.536570
Plate flat with rim 17 cm / 6.8 inch	6	001.536426
Plate flat with rim 15 cm / 6.0 inch	6	001.536282
Plate deep with rim 23 cm / 9.0 inch	6	001.537289
Plate deep with rim 19 cm / 7.5 inch	6	001.538465
Soup cup 0,30 ltr. / 10.0 oz.	6	001.537624
Saucer 1 15 cm / 5.9 inch	6	001.541802
Gravy boat 0,50 ltr. / 16.7 oz.	2	001.538656
Gravy boat 0,15 ltr. / 5.0 oz.	4	001.538824
Butter pad 0,04 ltr. / 1.3 oz.	2	001.538751
Bowl round 13 cm / 5.1 inch	6	001.537721
Bowl round 15 cm / 6.0 inch	4	001.537841
Bowl round 18 cm / 7.1 inch	2	001.537962
Bowl round 20 cm / 7.7 inch	2	001.538106
Bowl round 23 cm / 9.0 inch	2	001.538249
Bowl round 25 cm / 9.9 inch	2	001.538368
Oval platter 28 cm / 10.6 x 7.1 inch	2	001.539378
Oval platter 31 cm / 12.0 x 8.1 inch	2	001.539522
Oval platter 35 cm / 13.6 x 9.3 inch	2	001.539665
Oval platter 38 cm / 14.6 x 9.9 inch	2	001.539785
Oval platter 24 cm / 9.3 x 5.0 inch	2	001.539042

¹ PU = Packing Unit
² Item-No refers to undecorated articles



C

COUP FINE DINING

»FASHION«






C

COUP FINE DINING

»FASHION«

ITEM DESCRIPTION	PU ¹	Item-No	Airbrushed	Textured
 Coffee pot 0,38 ltr. / 13.3 oz.	2	001.742473 ² 001.742515 ³	●	
 Tea pot 0,65 ltr. / 21.7 oz.	2	001.742484 ² 001.742526 ³	●	
 Sugar bowl (LIFE) 0,26 ltr. / 8.7 oz.	1	001.744627 ² 001.744634 ³	●	
 Creamer (LIFE) 0,26 ltr. / 8.7 oz.	1	001.744628 ² 001.744635 ³	●	
 Mocha cup M5389 0,08 ltr. / 2.7 oz.	6	001.742474 ² 001.742516 ³	●	
 Tea cup (LIFE) 0,14 ltr. / 4.7 oz.	6	001.744625 ² 001.744632 ³	●	
 Coffee cup M5389 0,19 ltr. / 6.3 oz.	6	001.742475 ² 001.742517 ³	●	
 Cappuccino cup M5389 0,22 ltr. / 7.3 oz.	6	001.742476 ² 001.742518 ³	●	
 Tea cup (LIFE) 0,28 ltr. / 9.3 oz.	6	001.744626 ² 001.744633 ³	●	
 Milkcoffee cup M5389 0,35 ltr. / 11.7 oz.	6	001.742477 ² 001.742519 ³	●	

ITEM DESCRIPTION	PU ¹	Item-No	Airbrushed	Textured
 Mug with handle M5389 0,28 ltr. / 9.3 oz.	6	001.742478 ² 001.742520 ³	●	
 Mug with handle M5389 0,38 ltr. / 12.7 oz.	1	001.742479 ² 001.742521 ³	●	
 Saucer square small M5387 13 x 13 cm 5.2 x 5.2 inch*	6	001.742480 ² 001.742522 ³		●
 Saucer square big M5387 16 x 16 cm 6.3 x 6.3 inch**	6	001.742481 ² 001.742523 ³		●
 Saucer round small M5390 13,5 cm / 5.2 inch**	6	001.742482 ² 001.742524 ³		●
 Saucer round big M5390 16,5 cm / 6.5 inch**	6	001.742483 ² 001.742525 ³		●
 Showplate flat M5380 33 cm / 13.1 inch	4	001.742465 ² 001.742507 ³		●
 Plate flat coup M5380 30 cm / 12.0 inch	6	001.742447 ² 001.742489 ³		●
 Plate flat coup M5380 28 cm / 11.1 inch	6	001.742446 ² 001.742488 ³		●
 Plate flat coup M5380 26 cm / 10.3 inch	6	001.742445 ² 001.742487 ³		●
 Plate flat coup M5380 21,5 cm / 8.5 inch	6	001.742444 ² 001.742486 ³		●
 Plate flat coup M5380 16,5 cm / 6.5 inch	6	001.742443 ² 001.742485 ³		●

ITEM DESCRIPTION	PU ¹	Item-No	Airbrushed	Textured
 Bowl coup M5381 28 cm / 11.0 inch	4	001.742462 ² 001.742504 ³	●	
 Bowl coup M5381 26 cm / 10.3 inch	6	001.742461 ² 001.742503 ³	●	
 Bowl coup M5381 23 cm / 9.2 inch	6	001.742460 ² 001.742502 ³	●	
 Bowl coup M5381 20 cm / 7.9 inch	6	001.742459 ² 001.742501 ³	●	
 Bowl coup M5381 14,5 cm / 5.7 inch	6	001.742458 ² 001.742500 ³	●	
 Platter coup M5379 33 x 18 cm 13.0 x 7.0 inch	2	001.742470 ² 001.742512 ³		●
 Platter coup M5379 40 x 25,5 cm 15.9 x 10.2 inch	2	001.742466 ² 001.742508 ³		●
 Platter coup M5379 43 x 19 cm 17.1 x 7.5 inch	2	001.742467 ² 001.742509 ³		●
 Platter coup M5379 35 x 11 cm 13.9 x 4.5 inch	2	001.742469 ² 001.742511 ³		●
 Platter coup M5379 44 x 14 cm 17.4 x 5.6 inch	2	001.742468 ² 001.742510 ³		●
 Setplatter 44 cm / 17.5 x 5.6 inch	2	001.742472 ² 001.742514 ³		●
 Bowl high 0,18 ltr. / 6.3 oz.	6	001.742464 ² 001.742506 ³	●	
 Bowl low 0,21 ltr. / 6.7 oz.	6	001.742463 ² 001.742505 ³	●	



* suitable for mocha cup M5389 0,08 ltr. / 2.7 oz.,
tea cup 0,14 ltr. / 4.7 oz. (LIFE)

**suitable for all cups, except mocha cup M5389 0,08 ltr. / 2.7 oz.,
tea cup 0,14 ltr. / 4.7 oz. (LIFE)

¹ PU = Packing Unit

C

COUP FINE DINING

»FASHION«

ITEM DESCRIPTION	PU ¹	Item-No	Airbrushed	Textured
 Plate flat coup square M5383 29 x 29 cm 11.5 x 11.5 inch	4	001.742451 ² 001.742493 ³		●
 Plate flat coup square M5383 26 x 26 cm 10.2 x 10.2 inch	6	001.742450 ² 001.742492 ³		●
 Plate flat coup square M5383 22 x 22 cm 8.7 x 8.7 inch	6	001.742449 ² 001.742491 ³		●
 Plate flat coup square M5383 16,5 x 16,5 cm 6.5 x 6.5 inch	6	001.742448 ² 001.742490 ³		●
 Bowl coup square M5384 26 x 26 cm 10.2 x 10.2 inch	4	001.742456 ² 001.742498 ³	●	
 Bowl coup square M5384 22 x 22 cm 8.6 x 8.6 inch	6	001.742455 ² 001.742497 ³	●	
 Bowl coup square M5384 17,5 x 17,5 cm 6.9 x 6.9 inch	6	001.742454 ² 001.742496 ³	●	
 Bowl coup square M5384 13 x 13 cm 5.0 x 5.0 inch	6	001.742453 ² 001.742495 ³	●	
 Plate flat coup rectangular M5385 35 x 20 cm 14.0 x 8.0 inch	2	001.742452 ² 001.742494 ³		●
 Bowl coup rectangular M5386 25,5 x 18 cm 10.2 x 7.0 inch	2	001.742457 ² 001.742499 ³	●	
 Platter coup rectangular M5388 38 x 14 cm 15.2 x 5.6 inch	2	001.742471 ² 001.742513 ³		●
Tureen with lid 3,00 ltr. / 100.0 oz. (LIFE)	1	001.744622 ² 001.744629 ³	●	
Gravy boat (LIFE) 0,60 ltr. / 20.0 oz.	1	001.744623 ² 001.744630 ³	●	
Egg cup with rest (LIFE)	6	001.744624 ² 001.744631 ³	●	

 Airbrushed  Textured ² »old rose« 57270

 Airbrushed  Textured ³ »turquoise« 57271



C CUP FINE DINING

»FASHION«

ITEM DESCRIPTION PU¹ Item-No Airbrushed Textured

	Coffee pot 0,38 ltr. / 13.3 oz.	2	001.742557 ⁴ 001.742599 ⁵ 001.742641 ⁶	●	
	Tea pot 0,65 ltr. / 21.7 oz.	2	001.742568 ⁴ 001.742610 ⁵ 001.742652 ⁶	●	
	Sugar bowl 0,26 ltr. / 8.7 oz. (LIFE)	1	001.744641 ⁴ 001.744648 ⁵ 001.744655 ⁶	●	
	Creamer 0,26 ltr. / 8.7 oz. (LIFE)	1	001.744642 ⁴ 001.744649 ⁵ 001.744656 ⁶	●	
	Mocha cup M5389 0,08 ltr. / 2.7 oz.	6	001.742558 ⁴ 001.742600 ⁵ 001.742642 ⁶	●	
	Tea cup (LIFE) 0,14 ltr. / 4.7 oz.	6	001.744639 ⁴ 001.744646 ⁵ 001.744653 ⁶	●	
	Coffee cup M5389 0,19 ltr. / 6.3 oz.	6	001.742559 ⁴ 001.742601 ⁵ 001.742643 ⁶	●	
	Cappuccino cup M5389 0,22 ltr. / 7.3 oz.	6	001.742560 ⁴ 001.742602 ⁵ 001.742644 ⁶	●	
	Tea cup (LIFE) 0,28 ltr. / 9.3 oz.	6	001.744640 ⁴ 001.744647 ⁵ 001.744654 ⁶	●	
	Milkcoffee cup M5389 0,35 ltr. / 11.7 oz.	6	001.742561 ⁴ 001.742603 ⁵ 001.742645 ⁶	●	

ITEM DESCRIPTION PU¹ Item-No Airbrushed Textured

	Mug with handle M5389 0,28 ltr. / 9.3 oz.	6	001.742562 ⁴ 001.742604 ⁵ 001.742646 ⁶	●	
	Mug with handle M5389 0,38 ltr. / 12.7 oz.	1	001.742563 ⁴ 001.742605 ⁵ 001.742647 ⁶	●	
	Saucer square small M5387 13 x 13 cm 5.2 x 5.2 inch*	6	001.742564 ⁴ 001.742606 ⁵ 001.742648 ⁶		●
	Saucer square big M5387 16 x 16 cm 6.3 x 6.3 inch**	6	001.742565 ⁴ 001.742607 ⁵ 001.742649 ⁶		●
	Saucer round small M5390 13,5 cm / 5.2 inch**	6	001.742566 ⁴ 001.742608 ⁵ 001.742650 ⁶		●
	Saucer round big M5390 16,5 cm / 6.5 inch**	6	001.742567 ⁴ 001.742609 ⁵ 001.742651 ⁶		●
	Showplate flat M5380 33 cm / 13.1 inch	4	001.742549 ⁴ 001.742591 ⁵ 001.742633 ⁶		●
	Plate flat coup M5380 30 cm / 12.0 inch	6	001.742531 ⁴ 001.742573 ⁵ 001.742615 ⁶		●
	Plate flat coup M5380 28 cm / 11.1 inch	6	001.742530 ⁴ 001.742572 ⁵ 001.742614 ⁶		●
	Plate flat coup M5380 26 cm / 10.3 inch	6	001.742529 ⁴ 001.742571 ⁵ 001.742613 ⁶		●

ITEM DESCRIPTION PU¹ Item-No Airbrushed Textured

	Plate flat coup M5380 21,5 cm / 8.5 inch	6	001.742528 ⁴ 001.742570 ⁵ 001.742612 ⁶		●
	Plate flat coup M5380 16,5 cm / 6.5 inch	6	001.742527 ⁴ 001.742569 ⁵ 001.742611 ⁶		●
	Bowl coup M5381 28 cm / 11.0 inch	4	001.742546 ⁴ 001.742588 ⁵ 001.742630 ⁶	●	
	Bowl coup M5381 26 cm / 10.3 inch	6	001.742545 ⁴ 001.742587 ⁵ 001.742629 ⁶	●	
	Bowl coup M5381 23 cm / 9.2 inch	6	001.742544 ⁴ 001.742586 ⁵ 001.742628 ⁶	●	
	Bowl coup M5381 20 cm / 7.9 inch	6	001.742543 ⁴ 001.742585 ⁵ 001.742627 ⁶	●	
	Bowl coup M5381 14,5 cm / 5.7 inch	6	001.742542 ⁴ 001.742584 ⁵ 001.742626 ⁶	●	
	Platter coup M5379 33 x 18 cm 13.0 x 7.0 inch	2	001.742554 ⁴ 001.742596 ⁵ 001.742638 ⁶		●
	Platter coup M5379 40 x 25,5 cm 15.9 x 10.2 inch	2	001.742550 ⁴ 001.742592 ⁵ 001.742634 ⁶		●
	Platter coup M5379 43 x 19 cm 17.1 x 7.5 inch	2	001.742551 ⁴ 001.742593 ⁵ 001.742635 ⁶		●
	Platter coup M5379 35 x 11 cm 13.9 x 4.5 inch	2	001.742553 ⁴ 001.742595 ⁵ 001.742637 ⁶		●
	Platter coup M5379 44 x 14 cm 17.4 x 5.6 inch	2	001.742552 ⁴ 001.742594 ⁵ 001.742636 ⁶		●
	Setplatter 44 cm / 17.5 x 5.6 inch	2	001.742556 ⁴ 001.742598 ⁵ 001.742640 ⁶		●
	Bowl high 0,18 ltr. / 6.3 oz.	6	001.742548 ⁴ 001.742590 ⁵ 001.742632 ⁶	●	
	Bowl low 0,21 ltr. / 6.7 oz.	6	001.742547 ⁴ 001.742589 ⁵ 001.742631 ⁶	●	

* suitable for mocha cup M5389 0,08 ltr. / 2.7 oz.,
tea cup 0,14 ltr. / 4.7 oz. (LIFE)

**suitable for all cups, except mocha cup M5389 0,08 ltr. / 2.7 oz.,
tea cup 0,14 ltr. / 4.7 oz. (LIFE)

¹ PU = Packing Unit

C CUP FINE DINING

»FASHION«

ITEM DESCRIPTION PU¹ Item-No Airbrushed Textured

	Plate flat coup square M5383 29 x 29 cm 11.5 x 11.5 inch	4	001.742535 ⁴ 001.742577 ⁵ 001.742619 ⁶		●
	Plate flat coup square M5383 26 x 26 cm 10.2 x 10.2 inch	6	001.742534 ⁴ 001.742576 ⁵ 001.742618 ⁶		●
	Plate flat coup square M5383 22 x 22 cm 8.7 x 8.7 inch	6	001.742533 ⁴ 001.742575 ⁵ 001.742617 ⁶		●
	Plate flat coup square M5383 16,5 x 16,5 cm 6.5 x 6.5 inch	6	001.742532 ⁴ 001.742574 ⁵ 001.742616 ⁶		●
	Bowl coup square M5384 26 x 26 cm 10.2 x 10.2 inch	4	001.742540 ⁴ 001.742582 ⁵ 001.742624 ⁶	●	
	Bowl coup square M5384 22 x 22 cm 8.6 x 8.6 inch	6	001.742539 ⁴ 001.742581 ⁵ 001.742623 ⁶	●	
	Bowl coup square M5384 17,5 x 17,5 cm 6.9 x 6.9 inch	6	001.742538 ⁴ 001.742580 ⁵ 001.742622 ⁶	●	
	Bowl coup square M5384 13 x 13 cm 5.0 x 5.0 inch	6	001.742537 ⁴ 001.742579 ⁵ 001.742621 ⁶	●	
	Plate flat coup rectangular M5385 35 x 20 cm 14.0 x 8.0 inch	2	001.742536 ⁴ 001.742578 ⁵ 001.742620 ⁶		●
	Bowl coup rectangular M5386 25,5 x 18 cm 10.2 x 7.0 inch	2	001.742541 ⁴ 001.742583 ⁵ 001.742625 ⁶	●	
	Platter coup rectangular M5388 38 x 14 cm 15.2 x 5.6 inch	2	001.742555 ⁴ 001.742597 ⁵ 001.742639 ⁶		●
	Tureen with lid 3,00 ltr. / 100.0 oz. (LIFE)	1	001.744636 ⁴ 001.744643 ⁵ 001.744650 ⁶	●	
	Gravy boat 0,60 ltr. / 20.0 oz. (LIFE)	1	001.744637 ⁴ 001.744644 ⁵ 001.744651 ⁶	●	
	Egg cup with rest (LIFE)	6	001.744638 ⁴ 001.744645 ⁵ 001.744652 ⁶	●	

⁴ »grey« 57272

⁵ »anthracite« 57273

⁶ »black« 57350



C

COUP FINE DINING

»KARMA« 57423

ITEM DESCRIPTION	PU ¹	Item-No Karma 57423	Full decoration	Partial decoration
 Coffee pot 0,38 ltr. / 13.3 oz.	2	001.744569		●
 Tea pot 0,65 ltr. / 21.7 oz.	2	001.744570		●
 Sugar bowl (LIFE) 0,26 ltr. / 8.7 oz.	1	001.744571		●
 Creamer (LIFE) 0,26 ltr. / 8.7 oz.	1	001.744572		●
 Mocha cup M5389 0,08 ltr. / 2.7 oz.	6	001.744573		●
 Tea cup (LIFE) 0,14 ltr. / 4.7 oz.	6	001.744587		●
 Coffee cup M5389 0,19 ltr. / 6.3 oz.	6	001.744574		●
 Cappuccino cup M5389 0,22 ltr. / 7.3 oz.	6	001.744575		●
 Tea cup (LIFE) 0,28 ltr. / 9.3 oz.	6	001.744588		●
 Milkcoffee cup M5389 0,35 ltr. / 11.7 oz.	6	001.744576		●

ITEM DESCRIPTION	PU ¹	Item-No Karma 57423	Full decoration	Partial decoration
 Mug with handle M5389 0,28 ltr. / 9.3 oz.	6	001.744577		●
 Mug with handle M5389 0,38 ltr. / 12.7 oz.	1	001.744578		●
 Saucer square small M5387 13 x 13 cm 5.2 x 5.2 inch*	6	001.744579	●	
 Saucer square big M5387 16 x 16 cm 6.3 x 6.3 inch**	6	001.744580	●	
 Saucer round small M5390 13,5 cm / 5.2 inch**	6	001.744581	●	
 Saucer round big M5390 16,5 cm / 6.5 inch**	6	001.744582	●	
 Showplate flat M5380 33 cm / 13.1 inch	4	001.744539	●	
 Plate flat coup M5380 30 cm / 12.0 inch	6	001.744540	●	
 Plate flat coup M5380 28 cm / 11.1 inch	6	001.744541	●	
 Plate flat coup M5380 26 cm / 10.3 inch	6	001.744542	●	

C

COUP FINE DINING

»KARMA« 57423

ITEM DESCRIPTION	PU ¹	Item-No Karma 57423	Full decoration	Partial decoration
 Plate flat coup M5380 21,5 cm / 8.5 inch	6	001.744543	●	
 Plate flat coup M5380 16,5 cm / 6.5 inch	6	001.744544	●	
 Bowl coup M5381 28 cm / 11.0 inch	4	001.744545		●
 Bowl coup M5381 26 cm / 10.3 inch	6	001.744546		●
 Bowl coup M5381 23 cm / 9.2 inch	6	001.744547		●
 Bowl coup M5381 20 cm / 7.9 inch	6	001.744548		●
 Bowl coup M5381 14,5 cm / 5.7 inch	6	001.744549		●
 Platter coup M5379 33 x 18 cm 13.0 x 7.0 inch	2	001.744550	●	
 Platter coup M5379 40 x 25,5 cm 15.9 x 10.2 inch	2	001.744551	●	
 Platter coup M5379 43 x 19 cm 17.1 x 7.5 inch	2	001.744552	●	
 Platter coup M5379 35 x 11 cm 13.9 x 4.5 inch	2	001.744553	●	
 Platter coup M5379 44 x 14 cm 17.4 x 5.6 inch	2	001.744554	●	
 Setplatter 44 cm 17.5 x 5.6 inch	2	001.744555	●	
 Bowl high 0,18 ltr. / 6.3 oz.	6	001.744556		●
 Bowl low 0,21 ltr. / 6.7 oz.	6	001.744557		●

ITEM DESCRIPTION	PU ¹	Item-No Karma 57423	Full decoration	Partial decoration
 Plate flat coup square M5383 29 x 29 cm 11.5 x 11.5 inch	4	001.744558	●	
 Plate flat coup square M5383 26 x 26 cm 10.2 x 10.2 inch	6	001.744559	●	
 Plate flat coup square M5383 22 x 22 cm 8.7 x 8.7 inch	6	001.744560	●	
 Plate flat coup square M5383 16,5 x 16,5 cm 6.5 x 6.5 inch	6	001.744561	●	
 Bowl coup square M5384 26 x 26 cm 10.2 x 10.2 inch	4	001.744562		●
 Bowl coup square M5384 22 x 22 cm 8.6 x 8.6 inch	6	001.744563		●
 Bowl coup square M5384 17,5 x 17,5 cm 6.9 x 6.9 inch	6	001.744564		●
 Bowl coup square M5384 13 x 13 cm 5.0 x 5.0 inch	6	001.744565		●
 Plate flat coup rectangular M5385 35 x 20 cm 14.0 x 8.0 inch	2	001.744566	●	
 Bowl coup rectangular M5386 25,5 x 18 cm 10.2 x 7.0 inch	2	001.744567		●
 Platter coup rectangular M5388 38 x 14 cm 15.2 x 5.6 inch	2	001.744568	●	
 Tureen with lid 3,00 ltr. / 100.0 oz. (LIFE)	1	001.744584		●
 Gravy boat 0,60 ltr. / 20.0 oz. (LIFE)	1	001.744585		●
 Egg cup with rest (LIFE)	6	001.744586	●	



2 Full decoration
3 Partial decoration

* suitable for mocha cup M5389 0,08 ltr. / 2.7 oz.,
tea cup 0,14 ltr. / 4.7 oz. (LIFE)
** suitable for all cups, except mocha cup M5389 0,08 ltr. / 2.7 oz., tea cup
0,14 ltr. / 4.7 oz. (LIFE)

¹ PU = Packing Unit



C OUP FINE DINING

»FANTASTIC«

ITEM DESCRIPTION	PU¹	Item-No
Showplate flat M5380 33 cm / 13.0 inch	4	001.736067² 001.736071³ 001.736075⁴ 001.736079⁵ 001.749512⁶
Plate flat coup M5380 30 cm / 12.0 inch	6	001.736065² 001.736069³ 001.736073⁴ 001.736077⁵ 001.749513⁶
Plate flat coup M5380 28 cm / 11.0 inch	6	001.736282² 001.736312³ 001.736342⁴ 001.736372⁵ 001.749514⁶
Plate flat coup M5380 26 cm / 10.3 inch	6	001.736064² 001.736068³ 001.736072⁴ 001.736076⁵ 001.749515⁶
Plate flat coup M5380 21,5 cm / 8.5 inch	6	001.736281² 001.736311³ 001.736341⁴ 001.736371⁵ 001.749516⁶
Plate flat coup M5380 16,5 cm / 6.5 inch	6	001.736280² 001.736310³ 001.736340⁴ 001.736370⁵ 001.749517⁶

ITEM DESCRIPTION	PU¹	Item-No
Bowl coup M5381 28 cm / 11.0 inch	4	001.736066² 001.736070³ 001.736074⁴ 001.736078⁵ 001.749518⁶
Bowl coup M5381 26 cm / 10.3 inch	6	001.736286² 001.736316³ 001.736346⁴ 001.736376⁵ 001.749519⁶
Bowl coup M5381 23 cm / 9.2 inch	6	001.736285² 001.736315³ 001.736345⁴ 001.736375⁵ 001.749520⁶
Bowl coup M5381 20 cm / 7.9 inch	6	001.736284² 001.736314³ 001.736344⁴ 001.736374⁵ 001.749521⁶
Bowl coup M5381 14,5 cm / 5.7 inch	6	001.736283² 001.736313³ 001.736343⁴ 001.736373⁵ 001.749522⁶



- 2 »royal blue« 57122
- 3 »turquoise« 57123
- 4 »grey« 57124
- 5 »caramel« 57125
- 6 »brick red« 57126

C OUP FINE DINING

»FANTASTIC«

ITEM DESCRIPTION	PU¹	Item-No
Platter coup M5379 33 x 18 cm / 13.0 x 7.0 inch	2	001.736293² 001.736323³ 001.736353⁴ 001.736383⁵ 001.749523⁶
Platter coup M5379 40 x 25,5 cm / 16.0 x 10.2 inch	2	001.736289² 001.736319³ 001.736349⁴ 001.736379⁵ 001.749524⁶
Platter coup M5379 43 x 19 cm / 17.1 x 7.5 inch	2	001.736290² 001.736320³ 001.736350⁴ 001.736380⁵ 001.749525⁶
Platter coup M5379 35 x 11 cm / 13.9 x 4.5 inch	2	001.736292² 001.736322³ 001.736352⁴ 001.736382⁵ 001.749526⁶
Platter coup M5379 44 x 14 cm / 17.3 x 5.6 inch	2	001.736291² 001.736321³ 001.736351⁴ 001.736381⁵ 001.749527⁶
Setplatter 44 cm / 17.5 x 5.6 inch	2	001.736294² 001.736324³ 001.736354⁴ 001.736384⁵ 001.749528⁶
Bowl high 0,18 ltr. / 6.3 oz.	6	001.736288² 001.736318³ 001.736348⁴ 001.736378⁵ 001.749529⁶
Bowl low 0,21 ltr. / 6.6 oz.	6	001.736287² 001.736317³ 001.736347⁴ 001.736377⁵ 001.749530⁶



¹ PU = Packing Unit

ITEM DESCRIPTION	PU¹	Item-No
Coffee pot 1 0,36 ltr. / 12.0 oz.	2	001.736295² 001.736325³ 001.736355⁴ 001.736385⁵ 001.749531⁶
Sugar bowl 2 0,23 ltr. / 7.7 oz.	1	001.736296² 001.736326³ 001.736356⁴ 001.736386⁵ 001.749532⁶
Creamer 2 0,23 ltr. / 7.7 oz.	1	001.736297² 001.736327³ 001.736357⁴ 001.736387⁵ 001.749533⁶
Mocha cup 1132 0,09 ltr. / 3.0 oz.	6	001.736299² 001.736329³ 001.736359⁴ 001.736389⁵ 001.749535⁶
Saucer 1132 12 cm / 4.7 inch	6	001.736298² 001.736328³ 001.736358⁴ 001.736388⁵ 001.749534⁶
Cup 1163 0,18 ltr. / 6.0 oz.	6	001.736304² 001.736334³ 001.736364⁴ 001.736394⁵ 001.749536⁶
Saucer 1163 14,7 cm / 5.8 inch	6	001.736303² 001.736333³ 001.736363⁴ 001.736393⁵ 001.749537⁶
Cappuccino cup 1131 0,22 ltr. / 7.3 oz.	6	001.736302² 001.736332³ 001.736362⁴ 001.736392⁵ 001.749538⁶
Saucer 1131 14,7 cm / 5.8 inch	6	001.736301² 001.736331³ 001.736361⁴ 001.736391⁵ 001.749539⁶
Cup 1164 0,37 ltr. / 12.3 oz.	6	001.736306² 001.736336³ 001.736366⁴ 001.736396⁵ 001.749540⁶
Saucer 1164 16 cm / 6.3 inch	6	001.736305² 001.736335³ 001.736365⁴ 001.736395⁵ 001.749541⁶
Cup 5041 without handle 0,50 ltr. / 16.7 oz.	6	001.736300² 001.736330³ 001.736360⁴ 001.736390⁵ 001.749542⁶
Mug with handle 5005 0,25 ltr. / 8.3 oz. non stackable	6	001.736307² 001.736337³ 001.736367⁴ 001.736397⁵ 001.749543⁶
Mug with handle 5025 0,40 ltr. / 13.3 oz. non stackable	6	001.736308² 001.736338³ 001.736368⁴ 001.736398⁵ 001.749544⁶



BUFFET GOURMET


»FANTASTIC«

ITEM DESCRIPTION	PU ¹	Item-No	ITEM DESCRIPTION	PU ¹	Item-No
 Bowl 5140 15 x 15 cm / 6.0 x 6.0 inch	2	001.736096 ² 001.736128 ³ 001.736158 ⁴ 001.736188 ⁵ 001.749478 ⁶	 Dressing pot without lid 5140 1,00 ltr. / 33.3 oz.	1	001.736100 ² 001.736132 ³ 001.736162 ⁴ 001.736192 ⁵ 001.749482 ⁶
 Bowl 5140 20 x 20 cm / 8.0 x 8.0 inch	1	001.736097 ² 001.736129 ³ 001.736159 ⁴ 001.736189 ⁵ 001.749477 ⁶	 Platter 5170 16 x 16 cm / 6.3 x 6.3 inch	2	001.736101 ² 001.736133 ³ 001.736163 ⁴ 001.736193 ⁵ 001.749483 ⁶
 Bowl 5140 26 x 26 cm / 10.3 x 10.3 inch	1	001.736098 ² 001.736130 ³ 001.736160 ⁴ 001.736190 ⁵ 001.749478 ⁶	 Platter 5170 23 x 23 cm / 9.0 x 9.0 inch	1	001.736102 ² 001.736134 ³ 001.736164 ⁴ 001.736194 ⁵ 001.749484 ⁶
 Bowl 5160 25 x 25 x 7 cm / 9.9 x 9.9 inch	1	001.737860 ² 001.737861 ³ 001.737862 ⁴ 001.737863 ⁵ 001.749479 ⁶	 Platter 5170 32,5 x 22,4 cm / 12.8 x 4.3 inch	1	001.736103 ² 001.736135 ³ 001.736165 ⁴ 001.736195 ⁵ 001.749485 ⁶
 Bowl 5180 35 x 35 x 5 cm / 13.8 x 13.8 inch	1	001.737864 ² 001.737865 ³ 001.737866 ⁴ 001.737867 ⁵ 001.749480 ⁶	 Platter 5170 32,5 x 10,8 cm / 12.8 x 8.8 inch	1	001.736104 ² 001.736136 ³ 001.736166 ⁴ 001.736196 ⁵ 001.749486 ⁶
 Dessing pot without lid 5140 1,50 ltr. / 50.0 oz.	1	001.736099 ² 001.736131 ³ 001.736161 ⁴ 001.736191 ⁵ 001.749481 ⁶	 Platter 5170 32,5 x 32,5 cm / 12.8 x 12.8 inch	1	001.736105 ² 001.736137 ³ 001.736167 ⁴ 001.736197 ⁵ 001.749487 ⁶

¹ PU = Packing Unit
* fits: cooling tray stainless steel 7 inch

BUFFET GOURMET

»FANTASTIC«

ITEM DESCRIPTION	PU ¹	Item-No	ITEM DESCRIPTION	PU ¹	Item-No
 GN Platter 5170-1/1 53 x 32,5 cm / 20.8 x 12.8 inch	1	001.736106 ² 001.736138 ³ 001.736168 ⁴ 001.736198 ⁵ 001.749488 ⁶	 Bowl with cover 5120 3,50 ltr. / 150.0 oz.	1	001.736120 ² 001.736152 ³ 001.736182 ⁴ 001.736212 ⁵ 001.749502 ⁶
 GN Platter 5170-1/2 32,5 x 26,5 cm / 12.8 x 10.4 inch	2	001.736107 ² 001.736139 ³ 001.736169 ⁴ 001.736199 ⁵ 001.749489 ⁶	 Bowl without cover 5120 3,50 ltr. / 150.0 oz.	1	001.736121 ² 001.736153 ³ 001.736183 ⁴ 001.736213 ⁵ 001.749503 ⁶
 GN Platter 5170-1/3 32,5 x 17,6 cm / 12.8 x 7.0 inch	3	001.736108 ² 001.736140 ³ 001.736170 ⁴ 001.736200 ⁵ 001.749490 ⁶	 Cover for bowl 5120 17 cm / 6.7 inch	1	001.736122 ² 001.736154 ³ 001.736184 ⁴ 001.736214 ⁵ 001.749504 ⁶
 GN Platter 5170-2/4 53 x 16,2 cm / 20.8 x 6.4 inch	2	001.736109 ² 001.736141 ³ 001.736171 ⁴ 001.736201 ⁵ 001.749491 ⁶	 Bowl with cover 5140 2,00 ltr. / 66.6 oz.	1	001.736123 ² 001.736155 ³ 001.736185 ⁴ 001.736215 ⁵ 001.749505 ⁶
 Platter round 5120 18 cm / 9.0 inch*	1	001.736110 ² 001.736142 ³ 001.736172 ⁴ 001.736202 ⁵ 001.749492 ⁶	 Bowl without cover 5140 2,00 ltr. / 66.6 oz.	1	001.736124 ² 001.736156 ³ 001.736186 ⁴ 001.736216 ⁵ 001.749506 ⁶
 Bowl 5140 6 x 6 cm / 2.3 x 2.3 inch	6	001.736111 ² 001.736143 ³ 001.736173 ⁴ 001.736203 ⁵ 001.749493 ⁶	 Cover for bowl 5140 19,5 cm / 7.7 inch	1	001.736125 ² 001.736157 ³ 001.736187 ⁴ 001.736217 ⁵ 001.749507 ⁶
 Bowl 5140 10 x 10 cm / 3.9 x 3.9 inch	2	001.736112 ² 001.736144 ³ 001.736174 ⁴ 001.736204 ⁵ 001.749494 ⁶	 Bowl sloping 8,5 cm / 3.4 inch (SAVOY)	6	001.736080 ² 001.736084 ³ 001.736088 ⁴ 001.736092 ⁵ 001.749508 ⁶
 Bowl 5120 - 28/11 28 cm / 11.0 inch	1	001.736113 ² 001.736145 ³ 001.736175 ⁴ 001.736205 ⁵ 001.749495 ⁶	 Bowl sloping 11 cm / 4.4 inch (SAVOY)	6	001.736083 ² 001.736087 ³ 001.736091 ⁴ 001.736095 ⁵ 001.749509 ⁶
 Bowl with cover 5120 0,50 ltr. / 23.3 oz.	1	001.736114 ² 001.736146 ³ 001.736176 ⁴ 001.736206 ⁵ 001.749496 ⁶	 Bowl square 9 cm / 3.5 x 3.5 inch (SAVOY)	6	001.736081 ² 001.736085 ³ 001.736089 ⁴ 001.736093 ⁵ 001.749510 ⁶
 Bowl without cover 5120 0,50 ltr. / 23.3 oz.	1	001.736115 ² 001.736147 ³ 001.736177 ⁴ 001.736207 ⁵ 001.749497 ⁶	 Bowl square 11 cm / 4.8 x 4.8 inch (SAVOY)	6	001.736082 ² 001.736086 ³ 001.736090 ⁴ 001.736094 ⁵ 001.749511 ⁶
 Cover for bowl 5120 8 cm / 3.3 inch	1	001.736116 ² 001.736148 ³ 001.736178 ⁴ 001.736208 ⁵ 001.749498 ⁶			
 Bowl with cover 5120 1,50 ltr. / 63.3 oz.	1	001.736117 ² 001.736149 ³ 001.736179 ⁴ 001.736209 ⁵ 001.749499 ⁶			
 Bowl without cover 5120 1,50 ltr. / 63.3 oz.	1	001.736118 ² 001.736150 ³ 001.736180 ⁴ 001.736210 ⁵ 001.749500 ⁶			
 Cover for bowl 5120 11 cm / 4.3 inch	1	001.736119 ² 001.736151 ³ 001.736181 ⁴ 001.736211 ⁵ 001.749501 ⁶			

¹ PU = Packing Unit
* fits: cooling tray stainless steel 7 inch

2 »royal blue« 57122
3 »turquoise« 57123
4 »grey« 57124
5 »caramel« 57125
6 »brick red« 57126



C


COUP FINE DINING

»COUNTRY LIFE«

	ITEM DESCRIPTION	PU ¹	Item-No
	Showplate flat M5380 33 cm / 13.1 inch	4	001.731546 ² 001.731560 ³
	Plate flat coup M5380 30 cm / 12.0 inch	6	001.731540 ² 001.731554 ³
	Plate flat coup M5380 28 cm / 11.1 inch	6	001.731539 ² 001.731553 ³
	Plate flat coup M5380 26 cm / 10.3 inch	6	001.731538 ² 001.731552 ³
	Plate flat coup M5380 21,5 cm / 8.5 inch	6	001.731537 ² 001.731551 ³
	Plate flat coup M5380 16,5 cm / 6.5 inch	6	001.731536 ² 001.731550 ³
	Bowl coup M5381 28 cm / 11.0 inch	4	001.731545 ² 001.731559 ³
	Bowl coup M5381 26 cm / 10.3 inch	6	001.731544 ² 001.731558 ³
	Bowl coup M5381 23 cm / 9.2 inch	6	001.731543 ² 001.731557 ³
	Bowl coup M5381 20 cm / 7.9 inch	6	001.731542 ² 001.731556 ³
	Bowl coup M5381 14,5 cm / 5.7 inch	6	001.731541 ² 001.731555 ³
	Platter coup M5379 33 x 18 cm / 13.0 x 7.0 inch	2	001.733793 ² 001.733795 ³
	Platter coup M5379 40 x 25,5 cm / 15.9 x 10.2 inch	2	001.731547 ² 001.731561 ³
	Platter coup M5379 43 x 19 cm / 17.1 x 7.5 inch	2	001.731548 ² 001.731562 ³
	Platter coup M5379 35 x 11 cm / 13.9 x 4.5 inch	2	001.733792 ² 001.733794 ³
	Platter coup M5379 44 x 14 cm / 17.4 x 5.6 inch	2	001.731549 ² 001.731563 ³
	Setplatter 44 cm / 17.5 x 5.6 inch	2	001.732812 ² 001.732815 ³
	Bowl high 0,18 ltr. / 6.3 oz.	6	001.732811 ² 001.732814 ³
	Bowl low 0,21 ltr. / 6.7 oz.	6	001.732810 ² 001.732813 ³

¹ PU = Packing Unit

	ITEM DESCRIPTION	PU ¹	Item-No
	Coffee pot 1 0,36 ltr. / 12.0 oz.	2	001.731968 ² 001.731991 ³
	Sugar bowl 2 0,23 ltr. / 7.7 oz.	1	001.731969 ² 001.731992 ³
	Creamer 2 0,23 ltr. / 7.7 oz.	1	001.731970 ² 001.731993 ³
	Mocha cup 1132 0,09 ltr. / 3.0 oz.	6	001.731972 ² 001.731995 ³
	Saucer 1132 12 cm / 4.7 inch	6	001.731971 ² 001.731994 ³
	Cup 1163 0,18 ltr. / 6.0 oz.	6	001.731977 ² 001.732001 ³
	Saucer 1163 14,7 cm / 5.8 inch	6	001.731976 ² 001.731999 ³
	Cappuccino cup 1131 0,22 ltr. / 7.3 oz.	6	001.731975 ² 001.731998 ³
	Saucer 1131 14,7 cm / 5.8 inch	6	001.731974 ² 001.731997 ³
	Cup 1164 0,37 ltr. / 12.3 oz.	6	001.731979 ² 001.732003 ³
	Saucer 1164 16 cm / 6.3 inch	6	001.731978 ² 001.732002 ³
	Cup without handle 5041 0,50 ltr. / 16.7 oz.	6	001.731973 ² 001.731996 ³
	Mug with handle non stackable 5005 0,25 ltr. / 8.3 oz.	6	001.731989 ² 001.732004 ³
	Mug with handle non stackable 5025 0,40 ltr. / 13.3 oz.	6	001.731990 ² 001.732005 ³



»champagne« 57010

»petrol« 57011



C

COUP FINE DINING

»COUNTRY LIFE«

	ITEM DESCRIPTION	PU¹	Item-No
	Showplate flat M5380 33 cm / 13.1 inch	4	001.731574 ⁴ 001.731588 ⁵
	Plate flat coup M5380 30 cm / 12.0 inch	6	001.731568 ⁴ 001.731582 ⁵
	Plate flat coup M5380 28 cm / 11.1 inch	6	001.731567 ⁴ 001.731581 ⁵
	Plate flat coup M5380 26 cm / 10.3 inch	6	001.731566 ⁴ 001.731580 ⁵
	Plate flat coup M5380 21,5 cm / 8.5 inch	6	001.731565 ⁴ 001.731579 ⁵
	Plate flat coup M5380 16,5 cm / 6.5 inch	6	001.731564 ⁴ 001.731578 ⁵
	Bowl coup M5381 28 cm / 11.0 inch	4	001.731573 ⁴ 001.731587 ⁵
	Bowl coup M5381 26 cm / 10.3 inch	6	001.731572 ⁴ 001.731586 ⁵
	Bowl coup M5381 23 cm / 9.2 inch	6	001.731571 ⁴ 001.731585 ⁵
	Bowl coup M5381 20 cm / 7.9 inch	6	001.731570 ⁴ 001.731584 ⁵
	Bowl coup M5381 14,5 cm / 5.7 inch	6	001.731569 ⁴ 001.731583 ⁵
	Platter coup M5379 33 x 18 cm / 13.0 x 7.0 inch	2	001.733797 ⁴ 001.733799 ⁵
	Platter coup M5379 40 x 25,5 cm / 15.9 x 10.2 inch	2	001.731575 ⁴ 001.731589 ⁵
	Platter coup M5379 43 x 19 cm / 17.1 x 7.5 inch	2	001.731576 ⁴ 001.731590 ⁵
	Platter coup M5379 35 x 11 cm / 13.9 x 4.5 inch	2	001.733796 ⁴ 001.733798 ⁵
	Platter coup M5379 44 x 14 cm / 17.4 x 5.6 inch	2	001.731577 ⁴ 001.731591 ⁵
	Setplatter 44 cm / 17.5 x 5.6 inch	2	001.732818 ⁴ 001.732821 ⁵
	Bowl high 0,18 ltr. / 6.3 oz.	6	001.732817 ⁴ 001.732820 ⁵
	Bowl low 0,21 ltr. / 6.7 oz.	6	001.732816 ⁴ 001.732819 ⁵

¹ PU = Packing Unit

	ITEM DESCRIPTION	PU¹	Item-No
	Coffee pot 1 0,36 ltr. / 12.0 oz.	2	001.732006 ⁴ 001.732020 ⁵
	Sugar bowl 2 0,23 ltr. / 7.7 oz.	1	001.732007 ⁴ 001.732021 ⁵
	Creamer 2 0,23 ltr. / 7.7 oz.	1	001.732008 ⁴ 001.732022 ⁵
	Mocha cup 1132 0,09 ltr. / 3.0 oz.	6	001.732010 ⁴ 001.732024 ⁵
	Saucer 1132 12 cm / 4.7 inch	6	001.732009 ⁴ 001.732023 ⁵
	Cup 1163 0,18 ltr. / 6.0 oz.	6	001.732015 ⁴ 001.732029 ⁵
	Saucer 1163 14,7 cm / 5.8 inch	6	001.732014 ⁴ 001.732028 ⁵
	Cappuccino cup 1131 0,22 ltr. / 7.3 oz.	6	001.732013 ⁴ 001.732027 ⁵
	Saucer 1131 14,7 cm / 5.8 inch	6	001.732012 ⁴ 001.732026 ⁵
	Cup 1164 0,37 ltr. / 12.3 oz.	6	001.732017 ⁴ 001.732031 ⁵
	Saucer 1164 16 cm / 6.3 inch	6	001.732016 ⁴ 001.732030 ⁵
	Cup without handle 5041 0,50 ltr. / 16.7 oz.	6	001.732011 ⁴ 001.732025 ⁵
	Mug with handle non stackable 5005 0,25 ltr. / 8.3 oz.	6	001.732018 ⁴ 001.732032 ⁵
	Mug with handle non stackable 5025 0,40 ltr. / 13.3 oz.	6	001.732019 ⁴ 001.732033 ⁵



4 »olive« 57012



5 »terracotta« 57013



2 »Reflections« 57514
3 »Growth« 57516



C

COUP FINE DINING

»REFLECTIONS« | »GROWTH«

ITEM DESCRIPTION	PU ¹	Item-No
Showplate flat M5380 33 cm / 13.1 inch	4	001.749606 ² 001.749585 ³
Plate flat coup M5380 30 cm / 12.0 inch	6	001.749607 ² 001.749586 ³
Plate flat coup M5380 28 cm / 11.1 inch	6	001.749608 ² 001.749587 ³
Plate flat coup M5380 26 cm / 10.3 inch	6	001.749609 ² 001.749588 ³
Plate flat coup M5380 21,5 cm / 8.5 inch	6	001.749610 ² 001.749589 ³
Plate flat coup M5380 16,5 cm / 6.5 inch	6	001.749611 ² 001.749590 ³
Bowl coup M5381 28 cm / 11.0 inch	4	001.749612 ² 001.749591 ³
Bowl coup M5381 26 cm / 10.3 inch	6	001.749613 ² 001.749592 ³
Bowl coup M5381 23 cm / 9.2 inch	6	001.749614 ² 001.749593 ³

	Platter coup M5379 40 x 25,5 cm / 15.9 x 10.2 inch	2	001.749615 ² 001.749594 ³
	Platter coup M5379 43 x 19 cm / 17.1 x 7.5 inch	2	001.749616 ² 001.749595 ³
	Platter coup M5379 44 x 14 cm / 17.4 x 5.6 inch	2	001.749617 ² 001.749596 ³
	Plate flat coup square M5383 29 x 29 cm / 11.5 x 11.5 inch	4	001.749618 ² 001.749597 ³
	Plate flat coup square M5383 26 x 26 cm / 10.3 x 10.3 inch	6	001.749619 ² 001.749598 ³
	Plate flat coup square M5383 22 x 22 cm / 8.6 x 8.6 inch	6	001.749620 ² 001.749599 ³
	Plate flat coup square M5383 16,5 x 16,5 cm / 6.5 x 6.5 inch	6	001.749621 ² 001.749600 ³
	Bowl coup square M5384 26 x 26 cm / 10.0 x 10.0 inch	4	001.749622 ² 001.749601 ³
	Bowl coup square M5384 22 x 22 cm / 8.6 x 8.6 inch	6	001.749623 ² 001.749602 ³
	Plate flat coup rectangular 35 x 20 cm / M5385 14.0 x 8.0 inch	2	001.749624 ² 001.749603 ³
	Bowl coup rectangular M5386 25,5 x 18 cm / 10.0 x 7.0 inch	2	001.749625 ² 001.749604 ³
	Platter coup rectangular M5388 38 x 14 cm / 15.0 x 6.6 inch	2	001.749626 ² 001.749605 ³



¹ PU = Packing Unit








C

COUP FINE DINING

»BLUE SEA« 57515

	ITEM DESCRIPTION	PU ¹	Item-No
	Showplate flat M5380 33 cm / 13.1 inch	4	001.749686
	Plate flat coup M5380 30 cm / 12.0 inch	6	001.749687
	Plate flat coup M5380 28 cm / 11.1 inch	6	001.749688
	Plate flat coup M5380 26 cm / 10.3 inch	6	001.749689
	Plate flat coup M5380 21,5 cm / 8.5 inch	6	001.749690
	Plate flat coup M5380 16,5 cm / 6.5 inch	6	001.749691
	Bowl coup M5381 28 cm / 11.0 inch	4	001.749692
	Bowl coup M5381 26 cm / 10.3 inch	6	001.749693
	Bowl coup M5381 23 cm / 9.2 inch	6	001.749694

	ITEM DESCRIPTION	PU ¹	Item-No
	Platter coup M5379 40 x 25,5 cm / 15.9 x 10.2 inch	2	001.749695
	Platter coup M5379 43 x 19 cm / 17.1 x 7.5 inch	2	001.749696
	Platter coup M5379 44 x 14 cm / 17.4 x 5.6 inch	2	001.749697
	Plate flat coup square M5383 29 x 29 cm / 11.5 x 11.5 inch	4	001.749700
	Plate flat coup square M5383 26 x 26 cm / 10.3 x 10.3 inch	6	001.749702
	Plate flat coup square M5383 22 x 22 cm / 8.6 x 8.6 inch	6	001.749703
	Plate flat coup square M5383 16,5 x 16,5 cm / 6.5 x 6.5 inch	6	001.749705
	Bowl coup square M5384 26 x 26 cm / 10.0 x 10.0 inch	4	001.749706
	Bowl coup square M5384 22 x 22 cm / 8.6 x 8.6 inch	6	001.749708
	Plate flat coup rectangular 35 x 20 cm / M5385 14.0 x 8.0 inch	2	001.949709
	Bowl coup rectangular M5386 25,5 x 18 cm / 10.0 x 7.0 inch	2	001.749710
	Platter coup rectangular M5388 38 x 14 cm / 15.0 x 6.6 inch	2	001.749711



¹ PU = Packing Unit



MERAN

»SPRINGCOLORS«

ITEM DESCRIPTION	PU¹
Coffee pot 1 0,36 ltr. / 12.0 oz.	2
Tea pot 1 0,32 ltr. / 10.7 oz.	2
Sugar bowl 2 0,23 ltr. / 7.7 oz.	1
Sugar bowl 1164 0,37 ltr. / 12.3 oz.	6
Sugar dish 8,2 cm / 3.2 inch	12
Creamer 00 0,02 ltr. / 0.7 oz.	12
Creamer 1 0,15 ltr. / 5.0 oz.	1
Creamer 2 0,23 ltr. / 7.7 oz.	1
Espresso cup 5241 0,09 ltr. / 3.0 oz.	6
Saucer 5241 12,7 cm / 5.0 inch	6
Coffee cup 5242 0,20 ltr. / 6.7 oz.	6
Saucer 5242/5243 16,2 cm / 6.4 inch	6
Mug with handle DIVA 5156 0,35 ltr. / 13.3 oz.	6
Saucer 5156 17,5 cm / 6.9 inch	6
Saucer oval 19 cm / 7.4 x 5.0 inch	6
Saucer oval 21,5 cm / 8.5 x 6.0 inch	6
Plate flat 33 cm / 13.0 inch	6
Plate flat 30 cm / 12.0 inch	6
Plate flat 28 cm / 11.0 inch	6
Plate flat 26 cm / 10.2 inch	6
Plate flat 23 cm / 9.0 inch	6
Plate flat 20 cm / 8.0 inch	6
Plate flat 17 cm / 6.8 inch	6
Plate deep 23 cm / 8.9 inch	6
Bowl 1060 0,60 ltr. / 20.0 oz.	6

ITEM DESCRIPTION	PU¹
Coup plate flat oval 5234 21 cm / 8.3 x 7.6 inch	6
Coup plate flat oval 5195 25 cm / 9.8 x 9.0 inch	6
Coup plate flat oval 5193 27 cm / 10.6 x 9.7 inch	6
Coup plate flat oval 5192 29 cm / 11.9 x 11.0 inch	6
Coup plate flat oval 5235 34 cm / 13.4 x 12.0 inch	2
Coup plate flat round 5196 15,5 cm / 6.2 inch	6
Coup plate flat round 5197 17,5 cm / 7.0 inch	6
Coup plate flat round 5208 21,5 cm / 8.5 inch	6
Coup plate flat round 5209 25,5 cm / 10.0 inch	6
Coup plate flat round 5210 29 cm / 11.5 inch	6
Coup plate deep 5236 14,5 cm / 5.7 inch	6
Coup plate deep 5237 23 cm / 9.0 inch	6
Coup plate deep 5211 29 cm / 11.6 inch	6
Soup bowl oval 5238 16 cm / 6.0 x 5.3 inch	4
Bowl oval 5239 21 cm / 8.3 x 7.0 inch	2
Bowl oval 5240 25,5 cm / 10.0 x 8.5 inch	2
Bowl round 15 cm / 5.8 inch	4
Bowl round 20 cm / 7.8 inch	2
Bowl round 23 cm / 9.0 inch	2
Oval plate flat 25 cm / 9.8 x 6.4 inch	2
Oval plate flat 28 cm / 11.0 x 8.3 inch	2
Oval plate flat 31 cm / 12.3 x 9.0 inch	2
Oval plate flat 35 cm / 13.8 x 10.4 inch	2
Set salt and pepper	1
Coffee cup 1 0,18 ltr. / 6.0 oz. stackable	6
Saucer 1 16,2 cm / 6.4 inch	6



¹ PU = Packing Unit



- 1 »Brasilen« 23298
- 2 »Bolivien« 23299
- 3 »Costa Rica« 23300
- 4 »Kenia« 23301
- 5 »Vietnam« 23302
- 6 »Guatemala« 23303

Décor 23298 - 23303

	ITEM DESCRIPTION	PU¹
	Espresso cup 1132 0,09 ltr. / 3.0 oz.	6
	Saucer 1132 12 cm / 4.7 inch	6
	Cappuccino cup 1131 0,23 ltr. / 7.3 oz.	6
	Saucer 1131 14,5 cm / 5.8 inch	6
	Milkcoffee cup 1164 0,37 ltr. / 12.3 oz.	6
	Saucer 1164 16 cm / 6.3 inch	6
	Mug 5005 0,25 ltr. / 8.3 oz.	1
	Mug 5025 0,40 ltr. / 13.3 oz.	1
	Bowl 5121 13 cm / 5.1 inch	1
	Plate flat round 20 cm / 7.9 inch LUKULLUS 23304	6

Décor 10324 - 10328

	ITEM DESCRIPTION	PU¹
	Espresso cup 1132 0,09 ltr. / 3.0 oz.	6
	Saucer 1132 12 cm / 4.7 inch	6
	Jumbo cup 5041 0,50 ltr. / 16.7 oz.	1
	Saucer 5041 19 cm / 7.5 inch	6
	Cappuccino cup 1131 0,23 ltr. / 7.3 oz.	6
	Saucer 1131 14,5 cm / 5.8 inch	6
	Milkcoffee cup 1164 0,37 ltr. / 12.3 oz.	6
	Saucer 1164 16 cm / 6.3 inch	6
	Mug 5042 0,50 ltr. / 16.7 inch	1
	Mug 5005 0,25 ltr. / 8.3 oz.	1
	Mug 5025 0,40 ltr. / 13.3 oz.	1
	Plate flat round 20 cm / 7.9 inch*	6

Décor 22124 - 22129

	ITEM DESCRIPTION	PU¹
	Espresso cup 1132 0,09 ltr. / 3.0 oz.	6
	Saucer 1132 12 cm / 4.7 inch	6
	Cappuccino cup 1131 0,23 ltr. / 7.3 oz.	6
	Saucer 1131 14,5 cm / 5.8 inch	6
	Milkcoffee cup 1164 0,37 ltr. / 12.3 oz.	6
	Saucer 1164 16 cm / 6.3 inch	6
	Mug 5005 0,25 ltr. / 8.3 oz.	1
	Mug 5025 0,40 ltr. / 13.3 oz.	1
	Plate flat round 20 cm / 7.9 inch LUKULLUS 22130	6



- 1 »Massa« 22124
- 2 »Loreto« 22125
- 3 »Termoli« 22126
- 4 »Rapalo« 22127
- 5 »Grado« 22128
- 6 »Imperia« 22129



- 1 »red« 10324
- 2 »blue« 10325
- 3 »yellow« 10326
- 4 »green« 10327
- 5 »orange« 10328

¹ PU = Packing Unit
* Available in all colors.





BUFFET PLUS

DISCONTINUED AFTER 03/2020

ITEM DESCRIPTION	PU ¹	Item-No ²
Bowl triangle 5290 11 cm / 4.3 inch	4	001.697893
Bowl triangle 5290 20 cm / 7.8 inch	2	001.697894
Bowl triangle 5290 26 cm / 10.0 inch	2	001.697895
Bowl triangle 5290 31 cm / 12.5 inch	2	001.697896
Bowl triangle 5290 38 cm / 15.1 inch	2	001.697897
Bowl triangle high 5294 31 cm / 12.3 inch	2	001.697892
Bowl triangle 5291 9,5 cm / 3.8 inch	4	001.697900
Bowl triangle 5291 15 cm / 5.8 inch	2	001.697901
Bowl triangle 5291 19 cm / 7.9 inch	2	001.697902
Bowl triangle 5291 23 cm / 9.1 inch	2	001.697903
Bowl triangle 5291 28 cm / 11.0 inch	2	001.697904
Bowl triangle 5291 38 cm / 15.0 inch	1	001.697905

ITEM DESCRIPTION	PU ¹	Item-No ²
Bowl triangle high 5293 11 cm / 4.3 inch	2	001.697906
Dressing pot triangle 5292 1,00 ltr. / 33.3 oz.	1	001.697898
Dressing pot triangle 5292 1,85 ltr. / 61.7 oz.	1	001.697899



¹ PU = Packing Unit
² Item-No refers to undecorated articles



BUFFET GOURMET

ITEM DESCRIPTION	PU ¹	Item-No ²
Platter rect. 5140 16 x 16 cm / 6.2 x 6.2 inch	2	001.590330
Platter rect. 5140 25 x 25 cm / 10.0 x 10.0 inch	2	001.590405
Platter rect. 5140 25 x 14 cm / 10.0 x 5.6 inch	2	001.591283
Platter rect. 5140 35 x 14 cm / 14.0 x 5.6 inch	1	001.590505
Platter rect. 5140 35 x 25 cm / 14.0 x 10.0 inch	1	001.590530
Platter rect. 5140 35 x 35 cm / 14.0 x 14.0 inch	1	001.590580
Bowl 5140 11 x 11 cm / 4.3 x 4.3 inch	4	001.588734
Bowl 5140 15 x 15 cm / 6.0 x 6.0 inch	2	001.590205
Bowl 5140 17 x 17 cm / 6.6 x 6.6 inch	2	001.588759
Bowl 5140 20 x 20 cm / 8.0 x 8.0 inch	1	001.590255
Bowl 5140 23 x 23 cm / 9.0 x 9.0 inch	1	001.590630
Bowl 5140 26 x 26 cm / 10.2 x 10.2 inch	1	001.590655
Bowl 5140 6 x 6 cm / 2.4 x 2.4 inch	6	001.591508
Bowl 5140 10 x 10 cm / 4.0 x 4.0 inch	2	001.590680
Bowl 5140 10 x 20 cm / 8.0 x 4.0 inch	2	001.591583
Bowl 5140 5 x 20 cm / 8.0 x 2.0 inch	1	001.590105
Bowl 5140 5 x 30 cm / 12.0 x 2.0 inch	1	001.590155
Dressing pot 5140 1,50 ltr. / 50.0 oz.	1	001.589924
Dressing pot 5140 1,00 ltr. / 33.3 oz.	1	001.591458
Dressing pot 5140	12	001.591483



¹ PU = Packing Unit
² Item-No refers to undecorated articles

ITEM DESCRIPTION	PU ¹	Item-No ²
Bowl 5160 25 x 25 x 7 cm / 10.0 x 10.0 inch	2	001.589543
Bowl 5160 20 x 20 x 7 cm / 8.0 x 8.0 inch	2	001.589493
Bowl 5160 16 x 16 x 7 cm / 6.2 x 6.2 inch	1	001.589468
Bowl 5160 10 x 20 x 7 cm / 8.0 x 4.0 inch	1	001.589443
Bowl 5160 10 x 10 x 7 cm / 4.0 x 4.0 inch	1	001.737676
Platter rect. 5170 10 x 10 cm / 4.0 x 4.0 inch	2	001.589593
Platter rect. 5170 10 x 20 cm / 8.0 x 4.0 inch	2	001.589646
Platter rect. 5170 16 x 16 cm / 6.2 x 6.2 inch	2	001.589771
Platter rect. 5170 20 x 20 cm / 8.0 x 8.0 inch	2	001.589696
Platter rect. 5170 23 x 23 cm / 9.0 x 9.0 inch	1	001.659426
Platter rect. 5170 32,5 x 10,8 cm / 12.7 x 4.2 inch	1	001.659427
Platter rect. 5170 32,5 x 22,4 cm / 12.7 x 8.8 inch	1	001.659428
Platter rect. 5170 32,5 x 32,5 cm / 12.7 x 12.7 inch	1	001.659429
GN-Platter 5170-1/1 53 x 32,5 cm / 20.8 x 12.7 inch	1	001.700086
GN-Platter 5170-1/2 32,5 x 26,5 cm / 12.7 x 10.4 inch	2	001.700087
GN-Platter 5170-1/3 32,5 x 17,6 cm / 12.7 x 7.0 inch	3	001.700088
GN-Platter 5170-2/4 53 x 16,2 cm / 20.8 x 6.3 inch	2	001.700089
Bowl 5180 10 x 10 x 5 cm / 4.0 x 4.0 inch	4	001.590002
Bowl 5180 16 x 16 x 5 cm / 6.2 x 6.2 inch	1	001.589949
Bowl 5180 35 x 35 x 5 cm / 14.0 x 14.0 inch	1	001.737677





BUFFET GOURMET

	ITEM DESCRIPTION	PU ¹	Item-No ²
	Bowl 5120-18/8 18 cm / 7.0 inch	4	001.682250
	Bowl 5120-24/11 24 cm / 9.4 inch	2	001.682251
	Bowl 5120-28/11 28 cm / 11.0 inch	1	001.590305
	Bowl 5120-30/15 30 cm / 12.0 inch	1	001.590280
	Bowl with lid 5120 0,50 ltr. / 23.3 oz.	1	001.656976
	Bowl with lid 5120 1,50 ltr. / 63.3 oz.	1	001.656985
	Bowl with lid 5120 3,50 ltr. / 150.0 oz.	1	001.656994
	Bowl without lid 5140 2,00 ltr. / 66.7 oz.	1	001.588634
	Baker oval 22 x 14,5 cm / 8.7 x 5.7 inch (LUKULLUS)	1	001.103257
	Roaster rectangular (LUKULLUS) 30 x 18,5 cm / 12.0 x 7.3 inch	1	001.103733
	Roaster rectangular (LUKULLUS) 35 x 21,5 cm / 13.7 x 8.5 inch	1	001.103969
	Roaster rectangular (LUKULLUS) 38 x 24 cm / 15.0 x 9.4 inch	1	001.104127
	Souffle oval (LUKULLUS) 24 x 15 cm / 9.6 x 6.0 inch	1	001.104601
	Flan dish round (LUKULLUS) 18 cm / 7.2 inch	1	001.464117
	Toothpickholder 5140 5 x 4,5 cm / 1.7 inch	2	001.589846
	Creamer 5140	6	001.588541
	Sugarstickholder 5140	6	001.588491

¹ PU = Packing Unit
² Item-No refers to undecorated articles

GASTRONORMUNIT

ITEM DESCRIPTION	PU ¹	Item-No ²
GN-Unit 1/1 1402/121	1	001.591786
GN-Unit 1/2 1402/122	1	001.591836
GN-Unit 1/3 1402/123	1	001.591911
GN-Unit 1/4 1402/124	1	001.591961
GN-Unit 2/4 1402/224	1	001.592011
GN-Unit 1/3 1402/143	1	001.592161
GN-Unit 1/4 1402/144	1	001.592186
GN-Unit 2/4 1402/244	1	001.592061
GN-Unit 1/1 1402/101	1	001.591636
GN-Unit 1/2 1402/102	1	001.591661
GN-Unit 2/3 1402/203	1	001.591686
GN-Unit 1/3 1402/103	1	001.591711
GN-Unit 1/4 1402/104	1	001.591736
GN-Unit 2/4 1402/204	1	001.591761
GN-Unit 1/6 1402/106	1	001.592311





MUG TO GO

ITEM DESCRIPTION	PU ¹	Item-No ²
 Mug To Go 0,42 ltr. / 14.0 oz.	6	001.751057
 Lid to go	6	001.751058
 Sleeve to go	6	001.751059
 Mug To Go 0,42 ltr. / 14.0 oz.	1	001.751056

¹ PU = Packing Unit
² Item-No refers to undecorated articles





C COMMUNITY

ITEM DESCRIPTION	PU ¹	Item-No ²
Plate flat with rim 20 cm / 8.0 inch	6	001.743398
Plate flat with rim 23 cm / 9.0 inch	6	001.743399
Plate flat 25,5 cm / 10.0 inch	6	001.743400
Soup plate with rim 25,5 cm / 10.0 inch	6	001.743410
Plate deep 23 cm / 9.0 inch	6	001.743403
Salad plate 12 cm / 4.8 inch	4	001.743405
Salad plate 13,5 cm / 5.4 inch	4	001.743406
Coffee cup 0,18 ltr. / 6.0 oz.	6	001.743430
Coffee cup non stackable 0,22 ltr. / 7.3 oz.	6	001.743431
Saucer 1 15,5 cm / 6.0 inch	6	001.743432
Mug with handle 0,28 ltr. / 9.3 oz.	6	001.743433
Mug with two handles 0,28 ltr. / 9.3 oz.	6	001.743434
Soup cup 0,30 ltr. / 11.7 oz.	6	001.743404
Saucer 1 15,5 cm / 6.0 inch	6	001.743432
Coffee pot 1 0,38 ltr. / 12.7 oz.	2	001.743417
Tea pot 1 0,55 ltr. / 18.3 oz.	2	001.743420
Warming plate 1069 small	1	001.743435
Sugar bowl 2 0,28 ltr. / 9.3 oz.	1	001.743423
Creamer 1 0,15 ltr. / 5.0 oz.	1	001.743426
Creamer 2 0,25 ltr. / 8.3 oz.	1	001.743427
Mocha cup 0,09 ltr. / 3.0 oz.	6	001.743429
Saucer 13,5 cm / 5.4 inch	6	001.743428

¹ PU = Packing Unit
² Item-No refers to undecorated articles

ITEM DESCRIPTION	PU ¹	Item-No ²
Plate flat 30 cm / 12.0 inch	6	001.743402
Plate flat 28 cm / 11.3 inch	6	001.743401
Plate flat 17 cm / 6.7 inch	6	001.743397
Salad plate 19 cm / 7.5 inch	6	001.743411
Pasta plate deep 27 cm / 10.7 inch	2	001.743412
Gravy boat 0,45 ltr. / 15.7 oz.	2	001.743413
Bowl round 18 cm / 7.0 inch	2	001.743407
Bowl round 21 cm / 8.3 inch	2	001.743408
Bowl round 24 cm / 9.5 inch	2	001.743409
Oval platter 31 cm / 12.3 x 9.4 inch	2	001.743415
Oval platter 35 cm / 13.9 x 11.0 inch	2	001.743416
Vase	1	001.743436
Candleholder	1	001.743437
Egg cup with rest	6	001.743414





The saucers are moulded deep so that cups and mugs remain standing safely in the hollow of the saucer, even if tipped to an extreme angle.



The mug handles are designed to be big and easy to grasp. Additional protection prevents users from burning their fingers.



IMPERIAL

ITEM DESCRIPTION	PU ¹	Item-No ²
Coffee pot 1 0,35 ltr. / 11.8 oz.	2	001.560532
Tea pot 1 0,35 ltr. / 11.8 oz.	2	001.562645
Sugar bowl 2 0,20 ltr. / 6.7 oz.	1	001.564493
Creamer 4 0,15 ltr. / 5.0 oz.	1	001.565946
Creamer 5 0,30 ltr. / 10.0 oz.	1	001.566735
Coffee cup 1 0,18 ltr. / 6.0 oz.	6	001.570565
Saucer 1 16 cm / 6.3 inch	6	001.569905
Coffee cup 2 0,16 ltr. / 5.3 oz.	6	001.572016
Saucer 13,6 cm / 5.3 inch	12	001.568847
Milkcoffee cup 0,22 ltr. / 7.3 oz.	6	001.573468
Saucer 1 15,1 cm / 5.9 inch	6	001.569905
Egg cup with rest	6	001.555912
Plate flat with rim 30 cm / 12.0 inch	6	001.547201
Plate flat with rim 27 cm / 10.7 inch	6	001.546541
Plate flat with rim 25 cm / 10.0 inch	6	001.545881
Plate flat with rim 21 cm / 8.3 inch	6	001.545221
Plate flat with rim 19 cm / 7.5 inch	6	001.544692
Plate flat with rim 17 cm / 6.8 inch	6	001.544164
Plate flat with rim 15 cm / 6.0 inch	6	001.543767
Soup plate deep 23 cm / 9.0 inch	6	001.547860
Salad plate deep 19 cm / 7.5 inch	6	001.553404
Soup cup 0,30 ltr. / 10.0 oz.	6	001.549443
Saucer 1 15,1 cm / 5.9 inch	6	001.569905
Gravy boat 0,50 ltr. / 16.7 oz.	2	001.554724
Bowl round 13 cm / 5.3 inch	4	001.549972
Bowl round 15 cm / 6.0 inch	4	001.550500
Bowl round 18 cm / 7.0 inch	2	001.551029
Bowl round 21 cm / 8.3 inch	2	001.551689
Bowl round 23 cm / 9.0 inch	2	001.552348
Oval platter 28 cm / 11.0 x 8.0 inch	2	001.558553
Oval platter 31 cm / 12.2 x 9.1 inch	2	001.559213
Oval platter 35 cm / 13.8 x 10.2 inch	2	001.559872

¹ PU = Packing Unit

² Item-No refers to undecorated articles

VITALIS

ITEM DESCRIPTION	PU ¹	Item-No ²
Plate flat with rim 28 cm / 11.0 inch	6	001.492009
Plate flat with rim 25,5 cm / 10.0 inch	6	001.491687
Plate flat with rim 23 cm / 9.1 inch	6	001.491355
Plate flat with rim 20 cm / 7.9 inch	6	001.491111
Soup plate with rim 25,5 cm / 10.0 inch	6	001.494089
Plate deep 23 cm / 9.1 inch	6	001.492341
Cup 1 0,18 ltr. / 6.0 oz.	6	001.494929
Saucer 1 15,5 cm / 6.1 inch	6	001.494587
Mug with handle 0,30 ltr. / 10.0 oz.	6	001.495105
Mug with handle 0,25 ltr. / 8.3 oz.	6	001.495349
Mug with two handles 0,30 ltr. / 10.0 oz.	6	001.495525
Bowl round 16 cm / 6.3 inch	4	001.493239
Bowl round 16 cm / 6.3 inch	4	001.493561
Bowl round 12 cm / 4.7 inch	4	001.493825
Soup cup 0,35 ltr. / 11.6 oz.	6	001.492995
Saucer 17,5 cm / 6.9 inch	6	001.492663
Soup bowl with handle 0,50 ltr. / 16.7 oz. V203	6	001.495975
Compartment system platter 25,5 cm / 10.1 inch V219	2	001.496063



Spoons can easily be wiped off on the raised rims of flat and hollow items.

The famous »icing« on the cake...



Your cooking makes gourmets go into raptures.
The interior, decoration, accessoires, glasses ... **everything is of finest quality.**
There is only a small but essential detail missing

PORCELAIN WITH VIGNETTES



Your personal and distinctive logo on fine porcelain.
We can provide a quote – free of charge and obligation –
and a computer simulation for your customised porcelain.


Send us your templates and we'll do the rest!

SELTMANN WEIDEN – ... FROM SOLE PROPRIETORSHIP TO CORPORATE GROUP

The **Christian Seltmann Porcelain Factory** (SELTMANN-WEIDEN), founded in 1910, has evolved, through the takeover of the 'Royal Privileged Tettau Porcelain Factory' (KÖNIGLICH TETTAU) and the four specialist porcelain-manufacturers and art department absorbed in 1990 and 1995 to become a **group of companies** that is still today managed as a **family-run firm**. The group operates five factories employing around 1,000 people, producing exquisite porcelain for households, marketing – promotion – incentives, hotels and communal catering. It also creates stunning figurines and gifts.

As one of very few porcelain manufacturers to **operate worldwide**, the Seltmann Group possesses an unusually wide range of production expertise: from **high-tech production** in one of Europe's most modern porcelain manufacturing plants to the **craftsmanship** of traditional artisans working by hand at the Rudolstadt workshops in Thuringia.

Consequently, the porcelain produced by the Seltmann Group satisfies even the most exacting international demands in terms of design, function, resilience and exclusivity. It is precisely these product characteristics that can only be achieved at such **high standards** thanks to production in Germany. Reliability and flexibility are very important for the entrepre-



neurial Seltmann family, as well as the development of particularly **environmentally sound production techniques**, which are immediately incorporated into the production facilities.



be green

At SELTMANN WEIDEN, production in accordance with strict **environmental criteria** and **health guidelines** has always been a top priority.

To create a **credible, long-term** means of communicating this **eco-friendly approach** embraced by the whole Seltmann Group, Seltmann has developed an **environmental seal of quality** for its porcelain manufacturing activities.

MADE IN GERMANY

We produce in Germany

With its companies, the Seltmann Group has more than **250 years of experience** in the manufacture of porcelain. The ever-expanding **production expertise** passed down through the generations cannot to this day be replaced.



Porzellanfabriken Christian Seltmann GmbH
Postfach 2040 | 92610 Weiden/Germany
Tel: +49 (0) 961 / 204-0
Fax +49 (0) 961 / 204-119
E-Mail: hotel@seltmann.com

Homepage: hotel.seltmann.com



Ihr Fachhändler / *your dealer*: